

## ***TA880GU3+ BIOS Manual***

---

---

<b>BIOS Setup .....</b>	<b>1</b>
<b>1 Main Menu.....</b>	<b>3</b>
<b>2 Advanced Menu.....</b>	<b>6</b>
<b>3 PCI PnP Menu.....</b>	<b>16</b>
<b>4 Boot Menu.....</b>	<b>19</b>
<b>5 Chipset Menu.....</b>	<b>21</b>
<b>6 T-Series Menu.....</b>	<b>28</b>
<b>7 Exit Menu.....</b>	<b>42</b>

## **BIOS Setup**

### **Introduction**

The purpose of this manual is to describe the settings in the AMI BIOS Setup program on this motherboard. The Setup program allows users to modify the basic system configuration and save these settings to CMOS RAM. The power of CMOS RAM is supplied by a battery so that it retains theSetup information when the power is turned off.

Basic Input-Output System (BIOS) determines what a computer can do without accessing programs from a disk. This system controls most of the input and output devices such as keyboard, mouse, serial ports and disk drives. BIOS activates at the first stage of the booting process, loading and executing the operating system. Some additional features, such as virus and password protection or chipset fine-tuning options are also included in BIOS.

The rest of this manual will guide you through the options and settings in BIOS Setup.

### **Plug and Play Support**

This AMI BIOS supports the Plug and Play Version 1.0A specification.

### **EPA Green PC Support**

This AMI BIOS supports Version 1.03 of the EPA Green PC specification.

### **APM Support**

This AMI BIOS supports Version 1.1&1.2 of the Advanced Power Management (APM) specification. Power management features are implemented via the System Management Interrupt (SMI). Sleep and Suspend power management modes are supported. Power to the hard disk drives and video monitors can also be managed by this AMI BIOS.

### **ACPI Support**

AMI ACPI BIOS support Version 1.0/2.0 of Advanced Configuration and Power interface specification (ACPI). It provides ASL code for power management and device configuration capabilities as defined in the ACPI specification, developed by Microsoft, Intel and Toshiba.

## ***TA880GU3+ BIOS Manual***

---

### **PCI Bus Support**

This AMI BIOS also supports Version 2.3 of the Intel PCI (Peripheral Component Interconnect) local bus specification.

### **DRAM Support**


DDR3 SDRAM (Double Data Rate III Synchronous DRAM) is supported.

### **Supported CPUs**

This AMI BIOS supports the AMD CPU

### **Using Setup**

When starting up the computer, press **<Del>** during the **Power-On Self-Test (POST)** to enter the BIOS setup utility. In the BIOS setup utility, you will see **General Help** description at the top right corner, and this is providing a brief description of the selected item. **Navigation Keys** for that particular menu are at the bottom right corner, and you can use these keys to select item and change the settings.



### **Notice**


- The default BIOS settings apply for most conditions to ensure optimum performance of the motherboard. If the system becomes unstable after changing any settings, please load the default settings to ensure system's compatibility and stability. Use Load Setup Default under the Exit Menu.
- For better system performance, the BIOS firmware is being continuously updated. The BIOS information described in this manual is for your reference only. The actual BIOS information and settings on board may be slightly different from this manual.
- The content of this manual is subject to be changed without notice. We will not be responsible for any mistakes found in this user's manual and any system damage that may be caused by wrong-settings.

## ***TA880GU3+ BIOS Manual***

---

### **1 Main Menu**

Once you enter AMI BIOS Setup Utility, the Main Menu will appear on the screen providing an overview of the basic system information.



#### **AMI BIOS**

Shows system information, including BIOS version and built date.

#### **System Memory**

Shows system memory size.

#### **System Time**

Set the system internal clock.

#### **System Date**


Set the system date. Note that the 'Day' automatically changes when you set the date.

## **TA880GU3+ BIOS Manual**


---

### **SATA Configuration**

The BIOS will automatically detect the presence of SATA devices. There is a sub-menu for each SATA device. Select a device and press <Enter> to enter the sub-menu of detailed options.



### **SATA 1/2/3/4/5/6 Device**



The BIOS detects the information and values of respective devices, and these information and values are shown below to the name of the sub-menu.

## **TA880GU3+ BIOS Manual**

---

---

### ***Type***

Select the type of the IDE/SATA drive.

Options: Auto (Default) / CDROM / ARMD / Not Installed

### ***LBA/Large Mode***

Enable or disable the LBA mode.

Options: Auto (Default) / Disabled

### ***Block (MultiSector Transfer)***

Enable or disable multi-sector transfer.

Options: Auto (Default) / Disabled

### ***PIO Mode***

Select the PIO mode.

Options: Auto (Default) / 0 / 1 / 2 / 3 / 4

### ***DMA Mode***

Select the DMA mode.

Options: Auto (Default) / SWDMA0 ~ 2 / MWDMA0 ~ 2 / UDMA0 ~ 5

### ***S.M.A.R.T***

Set the Smart Monitoring, Analysis, and Reporting Technology.

Options: Auto (Default) / Disabled / Enabled

### ***32Bit Data Transfer***

Enable or disable 32-bit data transfer.

Options: Enabled (Default) / Disabled

### ***Hard Disk Write Protect***

Disable or enable device write protection. This will be effective only if the device is accessed through BIOS.

Options: Disabled (Default) / Enabled

### ***IDE Detect Time Out (Sec)***

Select the time out value for detecting IDE/SATA devices.

Options: 35 (Default) / 30 / 25 / 20 / 15 / 10 / 5 / 0

## ***TA880GU3+ BIOS Manual***


---

## **2 Advanced Menu**

The Advanced Menu allows you to configure the settings of CPU, Super I/O, Power Management, and other system devices.


### **Notice**

- Beware of that setting inappropriate values in items of this menu may cause system to malfunction.



### **CPU Configuration**

This item shows the CPU information that the BIOS automatically detects.



## ***TA880GU3+ BIOS Manual***

---

---

### **Secure Virtual Machine Mode**

Virtualization Technology can virtually separate your system resource into several parts, thus enhance the performance when running virtual machines or multi interface systems.

Options: Enabled (Default) / Disabled

### **PowerNow**

This item allows you to enable or disable the PowerNow power saving technology.

Options: Enabled (Default) / Disabled

### **ACPI SRAT Table**

The operating system scans the ACPI SRAT at boot time and uses the information to better allocate memory and schedule software threads for maximum performance. This item controls whether the SRAT is made available to the operating system at boot up, or not.

Options: Enabled (Default) / Disabled

### **Probe Filter**

This item allows you to set initialization mode for Probe Filter.

Options: Auto (Default) / Disabled / MP Mode

### **C1E Support**


This item allows you to configure the Enhanced Halt State (C1E) function, which may reduce the power consumption of your system when the system is idle.

Options: Enabled (Default) / Disabled

## **TA880GU3+ BIOS Manual**

---

### **SuperIO Configuration**



#### **Serial Port1 Address**

Select an address and corresponding interrupt for the first and second serial ports.  
Options: 3F8/IRQ4 (Default) / 2F8/IRQ3 / 3E8/IRQ4 / 2E8/IRQ3 / Disabled

#### **Parallel Port Address**

This item allows you to determine access onboard parallel port controller with which I/O Address.

Options: 378 (Default) / 278 / 3BC / Disabled

#### **Parallel Port Mode**

This item allows you to determine how the parallel port should function.

Options: Normal (Default) Using Parallel port as Standard Printer Port.  
EPP Using Parallel Port as Enhanced Parallel Port.  
ECP Using Parallel port as Extended Capabilities Port.  
ECP+EPP Using Parallel port as ECP & EPP mode

#### **ECP Mode DMA Channel**

This item allows you to select parallel port ECP DMA.

Options: DMA3 (Default) / DMA0 / DMA1

## **TA880GU3+ BIOS Manual**

---

---

### **Parallel Port IRQ**

This item allows you to select the IRQ for the onboard parallel port.  
Options: IRQ7 (Default) / IRQ5 / Disabled

### **OnBoard CIR Port**

This item allows you to enable or disable Consumer IR Port.  
Options: Disabled (Default) / Enabled

### **CIR Port IRQ**

This item allows you to select Consumer IR Port IRQ.  
Options: IRQ10 (Default) / IRQ3 / IRQ4 / IRQ11

### **Keyboard PowerOn**

This item allows you to control the keyboard power on function.  
Options: Disabled (Default) / Specific Key / Stroke Key / Any Key

### **Specific Key Enter**

This item will show only when Keyboard PowerOn is set “Specific Key.”

### **Stroke Keys Selected**

This item will show only when Keyboard PowerOn is set “Stroke Key.”  
Options: Ctrl+F1 (Default) / Wake Key / Power Key / Ctrl+F2 / Ctrl+F3 /  
Ctrl +F4 / Ctrl+F5 / Ctrl+F6

### **Mouse PowerOn**

This item allows you to control the mouse power on function.  
Options: Disabled (Default) / Enabled

### **Restore on AC Power Loss**


This setting specifies how your system should behave after a power fail or interrupt occurs. By choosing Disabled will leave the computer in the power off state. Choosing Enabled will restore the system to the status before power failure or interrupt occurs.

Options: Power Off (Default) / Power ON / Last State

## **TA880GU3+ BIOS Manual**

---

### **Smart Fan Configuration**



#### **CPU Smart Fan**

This item allows you to control the CPUSmart Fan function.  
Options: Disabled (Default) / Auto / 4Pin / 3Pin

#### **Smart Fan Calibration**

Choose this item and then the BIOS will auto test and detect the CPU/System fan functions and show CPU/System fan speed.

#### **Control Mode**

This item provides several operation modes of the fan.  
Options: Quiet / Performance / Manual

#### **Fan Ctrl OFF(°C)**

If the CPU/System Temperature is lower than the set value, FAN will turn off.  
Options: 0~127 ( °C ) (With the interval of 1°C)

#### **Fan Ctrl On(°C)**

CPU/System fan starts to work under smart fan function when arrive this set value.  
Options: 0~127 ( °C ) (With the interval of 1°C)

## **TA880GU3+ BIOS Manual**

---

### **Fan Ctrl Start Value**

When CPU/System temperature arrives to the set value, the CPU/System fan will work under Smart Fan Function mode.

Options: 0~127 (With the interval of 1)


### **Fan Ctrl Sensitive**

Increasing the value will raise the speed of CPU/System fan.

Options: 1~127 (With the interval of 1)

### **Hardware Health Configuration**

This item shows the system temperature, fan speed, and voltage information.



### **H/W Health Function**

If with a monitoring system, the system will show PC health status during POST stage.

Options: Enabled (Default) / Disabled

### **Shutdown Temperature**


This item allows you to set up the CPU shutdown Temperature. This item is only effective under Windows 98 ACPI mode.

Options: Disabled (Default) / 60°C/140°F / 65°C/149°F / 70°C/158°F / 75°C/167°F  
/ 80°C/176°F / 85°C/185°F / 90°C/194°F

## **TA880GU3+ BIOS Manual**

---

### **ACPI Configuration**



#### **EuP Control**

This item is used to enable or disable EuP Control ((Energy Using Products).  
Options: Disabled (Default) / Enabled

#### **Suspend mode**

The item allows you to select the suspend type under the ACPI operating system.  
Options: S1 (POS) (Default)      Power on Suspend  
          S3 (STR)                Suspend to RAM  
          S1 & S3                POS+STR

#### **ACPI Version Features**

The item allows you to select the version of ACPI  
Options: ACPI v3.0 (Default) / ACPI v1.0 / ACPI v2.0

#### **ACPI APIC support**

This item is used to enable or disable the motherboard's APIC (Advanced Programmable Interrupt Controller). The APIC provides multiprocessor support, more IRQs and faster interrupt handling.  
Options: Enabled (Default) / Disabled

## **TA880GU3+ BIOS Manual**

---

---

### **AMI OEMB table**

Set this value to allow the ACPI BIOS to add a pointer to an OEMB table in the Root System Description Table (RSDT) table.

Options: Enabled (Default) / Disabled

### **Headless mode**

This is a server-specific feature. A headless server is one that operates without a keyboard, monitor or mouse. To run in headless mode, both BIOS and operating system (e.g. Windows Server 2003) must support headless operation.

Options: Disabled (Default) / Enabled

### **RTC Resume**

When “Enabled”, you can set the date and time at which the RTC (real-time clock) alarm awakens the system from Suspend mode.

Options: Disabled (Default) / Enabled

### **RTC Alarm Date (Days)**

You can choose which date the system will boot up.

### **RTC Alarm Time**

You can choose the system boot up time, input hour, minute and second to specify.

### **USB Wakeup from S3/S4**

This item allows you to enable or disabled the USB resume from S3/S4 function.

Options: Disabled (Default) / Enabled

### **Power On by LAN**

This item allows you control the wake on LAN (WOL) function.

Options: Disabled (Default) / Enabled

### **Wakeup On Ring**

This item allows you control the wakeup on ring function.


Options: Disabled (Default) / Enabled

## **TA880GU3+ BIOS Manual**

---

### **USB Configuration**

This item shows the USB controller and using USB device information.



#### **Legacy USB Support**

This item determines if the BIOS should provide legacy support for USB devices like the keyboard, mouse, and USB drive. This is a useful feature when using such USB devices with operating systems that do not natively support USB (e.g. Microsoft DOS or Windows NT).

Options: Enabled (Default) / Disabled

#### **USB 2.0 Controller Mode**

This item allows you to select the operation mode of the USB 2.0 controller.

Options: HiSpeed (Default) USB 2.0-480Mbps  
FullSpeed USB 1.1-12Mbps

#### **BIOS EHCI Hand-Off**

This item allows you to enable support for operating systems without an EHCI hand-off feature.

Options: Enabled (Default) / Disabled

#### **Legacy USB1.1 HC Support**


This item allows you to enable to support USB1.1 HC.

Options: Enabled (Default) / Disabled

## ***TA880GU3+ BIOS Manual***

---

### **USB Mass Storage Device Configuration**



#### ***USB Mass Storage Reset Delay***

This item allows you to set the reset delay for USB mass storage device.  
Options: 20 Sec (Default) / 10 Sec / 30 Sec / 40 Sec

#### ***Emulation Type***

This item allows you to select the emulation type of the USB mass storage device.  
Options: Auto (Default) / Floppy / Forced FDD / Hard Disk / CDROM

## **TA880GU3+ BIOS Manual**


---

### **3 PCI PnP Menu**

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself when communicating with its own special components.

#### **Notice**

- Beware of that setting inappropriate values in items of this menu may cause system to malfunction.



#### **Clear NVRAM**

This item allows you to clear the data in the NVRAM (CMOS) by selecting “Yes”.  
Options: No (Default) / Yes

#### **Plug & Play OS**

When set to YES, BIOS will only initialize the PnP cards used for the boot sequence (VGA, IDE, SCSI). The rest of the cards will be initialized by the PnP operating system like Window™ 95. When set to NO, BIOS will initialize all the PnP cards. For non-PnP operating systems (DOS, Netware™), this option must set to NO.  
Options: No (Default) / Yes

## ***TA880GU3+ BIOS Manual***

---

### **PCI Latency Timer**

This item controls how long a PCI device can hold the PCI bus before another takes over. The longer the latency, the longer the PCI device can retain control of the bus before handing it over to another PCI device.

Options: 64 (Default) / 0-255

### **Allocate IRQ to PCI VGA**

This item allows BIOS to choose a IRQ to assign for the PCI VGA card.

Options: Yes (Default) / No

### **Palette Snooping**

Some old graphic controllers need to “snoop” on the VGA palette and then map it to their display as a way to provide boot information and VGA compatibility. This item allows such snooping to take place.


Options: Disabled (Default) / Enabled

### **PCI IDE BusMaster**

This item is a toggle for the built-in driver that allows the onboard IDE controller to perform DMA (Direct Memory Access) transfers.

Options: Enabled (Default) / Disabled

### **PCI Resource**



## ***TA880GU3+ BIOS Manual***

---

---

### **IRQ3/4/5/7/9/10/11/14/15**

These items will allow you to assign each system interrupt a type, depending on the type of device using the interrupt. The option “Available” means the IRQ is going to assign automatically.

Options: Available (Default) / Reserved

### **DMA Channel 0/1/3/5/6/7**

These items will allow you to assign each DMA channel a type, depending on the type of device using the channel. The option “Available” means the channel is going to assign automatically.

Options: Available (Default) / Reserved

### **Reserved Memory Size**

This item allows BIOS to reserve certain memory size for specific PCI device.


Options: Disabled (Default) / Enabled

## ***TA880GU3+ BIOS Manual***

---

## **4 Boot Menu**

This menu allows you to setup the system boot options.



### **Boot Device Priority**

Items in this sub-menu specify the boot device priority sequence from the available devices. The number of device items that appears on the screen depends on the number of devices installed in the system.

Options: Removable / Hard Disk / CDROM / Legacy LAN / Disabled

### **Hard Disk Drives**

The BIOS will attempt to arrange the hard disk boot sequence automatically. You can also change the booting sequence. The number of device items that appears on the screen depends on the number of devices installed in the system.

Options: Pri. Master / Pri. Slave / Sec. Master / Sec. Slave / USB HDD0 /  
USB HDD1 / USB HDD2 / Bootable Add-in Cards

### **CD/DVD Drives**

The BIOS will attempt to arrange the CD/DVD drive boot sequence automatically. You can also change the booting sequence. The number of device items that appears on the screen depends on the number of devices installed in the system.

Options: Pri. Master / Pri. Slave / Sec. Master / Sec. Slave / USB CDROM0 /  
USB CDROM 1

## ***TA880GU3+ BIOS Manual***

---

### **Quick Boot**

Enabling this option will cause an abridged version of the Power On Self-Test (POST) to execute after you power up the computer.

Options: Enabled (Default) / Disabled

### **Full Screen LOGO Show**

This item allows you to enable/disable Full Screen LOGO Show function.

Options: Enabled (Default) / Disabled

### **AddOn ROM Display Mode**

This item sets the display mode for option ROM.

Options: Force BIOS (Default) / Keep Current

### **Boot up Num-Lock**

Selects the NumLock State after the system switched on.

Options: ON (Default) / OFF

### **Interrupt 19 Capture**

When set to Enabled, this item allows the option ROMs to trap interrupt 19.

Options: Disabled (Default) / Enabled

### **Ignore Memory Error Messages**

When set to Enabled, BIOS would ignore memory error messages.

Options: Disabled (Default) / Enabled

### **Smart Multi-Core**

Options: Auto (Default) / Disabled

### **BOOT SUCCESS BEEP**

When this item is set to Enabled, BIOS will let user know boot success with beep.


Options: Enabled (Default) / Disabled

## ***TA880GU3+ BIOS Manual***


---

### **5 Chipset Menu**

This submenu allows you to configure the specific features of the chipset installed on your system. This chipset manage bus speeds and access to system memory resources, such as DRAM. It also coordinates communications with the PCI bus.




#### **NorthBridge Configuration**



## TA880GU3+ BIOS Manual

---

### Internal Graphics Configuration



#### ***Internal Graphics Mode***

This item allows you to select the memory mode used for internal graphics device.  
Options: UMA (Default) / Disable

#### ***UMA FrameBuffer Size***

This item allows you to choose the UMA frame buffer size for internal graphics.  
Options: Auto (Default) / 32MB / 64MB / 128MB / 256MB / 512MB / 1024MB

#### ***Surround View***

This item allows you to control the Surround View Function.  
Options: Auto (Default) / Disabled

#### ***FB Location***

This item allows you to set the FB-DIMM location.  
Options: Above 4G (Default) / Under 4G

#### ***AMD NB HD Audio***

This item allows you to activate HD Audio.  
Options: Enable (Default) / Disable


#### ***VBIOS Type***

This item allows you to select the type of video BIOS.  
Options: HDMI (Default) / DVI


## TA880GU3+ BIOS Manual

---

### PCI Express Configuration



### Port #02//04/05/06/07/09 Features



#### **Gen2 High Speed Mode**

Options: Disabled (Default) / Auto

#### **Link ASPM**

Options: Disabled (Default) / L0s / L1 / L0x & L1

#### **Link Width (Only for Port #02)**

Options: Auto (Default) / x1 / x2 / x4 / x8 / x16


## **TA880GU3+ BIOS Manual**

---

### ***Slot Power Limit, W (Only for Port #02)***

Options: 75 (Default) / 0-255

### ***NB-SB Port Features***



### ***NB-SB Link ASPM***

Options: L1 (Default) / Disabled

### ***NP NB-SB VC1 Traffic Support***

Options: Disabled (Default) / Enabled

### ***Link Width***

Options: Auto (Default) / x1 / x2 / x4

### ***Primary Video Controller***

This option allows you to select the video controller in charge.

Options: PCI-GFX0-GPP-IGFX (Default) / GFX0-GPP-IGFX-PCI /  
GPP-GFX0-IGFX-PCI / IGFX-GFX0-GPP-PCI

### ***NB Power Management Features***


This option controls the NB power management function.

Options: Auto (Default) / Disabled


## **TA880GU3+ BIOS Manual**

---

### **SouthBridge Configuration**



### **SB Azalia Audio Configuration**



#### ***HD Audio Azalia Device***


This item allows you to control the HD audio device.

Options: Enabled (Default) / Auto / Disabled

## TA880GU3+ BIOS Manual

---


### SB USB Configuration



#### *OHCI HC (Bus 0 Dev 18/19/20/22 Fn 0/5)*

This item allows you to control OHCI host controller. (USB 1.1 Device)  
Options: Enabled (Default) / Disabled

### SB SATA Configuration



#### *OnChip SATA Channel*

This option allows you to enable the on-chip Serial ATA.  
Options: Enabled (Default) / Disabled

## **TA880GU3+ BIOS Manual**

---

### ***OnChip SATA Type***

This option allows you to select the on-chip Serial ATA operation mode.

Options: Native IDE (Default) / RAID / AHCI / Legacy IDE / IDE→AHCI

### ***SATA IDE CombinedMode***

This option controls the SATA/PATA combined mode.


Options: Enabled (Default) / Disabled

### ***SATA III Mode***

This option allows you to limit SATA Capability.

Options: Enabled (Default) / Disabled

## **Onboard Peripherals Configuration**



### ***MAC ID Information***

This area shows the MAC ID.

### ***Realtek PCIE NIC***

This option allows you to control the onboard LAN controller.

Options: Enable (Default) / Disable

### ***Realtek Option ROM***

This item allows you to enable or disable the Onboard LAN Boot ROM.

Options: Disabled (Default) / Enabled

### ***USB 3.0 Controller***

This item allows you to enable or disable USB 3.0 Controller.


Options: Disabled (Default) / Enabled

## **6 T-Series Menu**

This submenu allows you to change voltage and clock of various devices.  
(However, we suggest you use the default setting. Changing the voltage and clock improperly may damage the device.)

### **Notice**

- Beware of that setting inappropriate values in items of this menu may cause system to malfunction.



### **BIO-unlockING**

This item allows you to activate BIO-unlockING function.  
Options: Disabled(Default) / Enabled


### **OverClock Navigator**

OverClock .Navigator is designed for beginners in overclock field.  
Based on many test and experiments from Biostar Engineer Team, OverClock Navigator provides 3 default overclock configurations that are able to raise the system performance.  
Options: Normal (Default) / Automate OverClock / Manual OverClock

## **TA880GU3+ BIOS Manual**

---

### **Auto OverClock System**



The Overclock Navigator provides 3 different engines helping you to overclock your system. These engines will boost your system performance to different level.

Options:

V6 Tech Engine

This engine will make a good over-clock performance.

V8 Tech Engine

This engine will make a better over-clock performance.

V12 Tech Engine

This engine will make a best over-clock performance.


#### **Cautions:**

Not every AMD CPU performs the above overclock setting ideally; the difference may vary with the installed CPU model.

## ***TA880GU3+ BIOS Manual***

---

### **Manual Overclock System (M.O.S.)**



MOS is designed for experienced overclock users.  
It allows users to customize personal overclock setting.

### **CPU/HT Reference Clock (MHz)**

This item allows BIOS to select CPU Over Clock.  
Options: 200 (Default) / 200~600


### **CPU Configuration**

This item allows you to save CPU configuration.  
Options: Auto (Default) / Configure 1~7

## **TA880GU3+ BIOS Manual**

---

### **CPU Tuning**



#### **CPU Vcore**

This item allows you to select CPU Voltage Control.

#### **CPU NB Over Voltage**

This item allows you to select CPU NB Voltage Control.

#### **Custom P-States**

This item tells BIOS whether to use the setup options below this to configure the P-States, or whether to configure the P-States automatically.

Options: Disabled (Default) / Enabled

#### **Core FID**

This item allows you to select the Ratio/Frequency of AM3 CPU.  
Options: x8.0 1600MHz ~ x31.5 6300MHz (Differed by CPU)

#### **Core VID**

This function allows you to adjust the voltage of AM3 CPU.

## ***TA880GU3+ BIOS Manual***

---

---

### **Core DID**

This is the Core Divider.

Options: Divided by 1 (Default) / Divided by 2 / Divided by 4 / Divided by 8 /  
Divided by 16

### **NB VID**

This function allows you to adjust the vdtage of NB chip.

### **NB FID**

This item allows you to select the Frequency of NB chip.

Options: 800MHz ~ 7000MHz (Differed by CPU)

### **NB DID**

This item is the NB Divider.

Options: Divided by 1 (Default) / Divided by 2

### **Link Speed**

The HyperTransport link will run at this speed if it is slower than or equal to the system clock and the board is capable.

Options: Auto (Default) / 200MHz / 400MHz / 600MHz / 800MHz / 1GHz /  
1.2GHz / 1.4GHz / 1.6GHz / 1.8GHz / 2.0GHz

### **Link Width**

The HyperTransport link will run at this width.

Options: Auto (Default) / 8 Bit / 16 Bit

### **Core Leveling**

This item allows you to activate Core Leveling function.

Options: Auto (Default) / Manual


### **CPU Core0/1/2/3**

Options: Enabled (Default) / Disabled

## **TA880GU3+ BIOS Manual**

---

### **Clock Control**



#### **ATIG/SB Reference Clock (MHz)**

This item allows you to select ATIG/SB Reference Clock.  
Options: 100 (Default) / 101~500

#### **Spread Spectrum**

This item allows you to control Spread Spectrum function.  
Options: Disabled (Default) / Enabled

#### **GFX Engine Clock Override**

This item allows you to control the internal GFX engine clock override function.  
Options: Disabled (Default) / Enabled


#### **GFX Engine Clock**

This item allows BIOS to select onboard GPU Over Clock.  
Options: 700 (Default) / 150 ~ 1500

## ***TA880GU3+ BIOS Manual***

---

### **Voltage Configuration**



#### **Memory Over Voltage**

This item allows you to change Memory voltage value.

#### **NB Over Voltage**

This item allows you to change NB voltage value.


#### **HT Over Voltage**

This item allows you to change HT voltage value.


## TA880GU3+ BIOS Manual

---

### DRAM Timing Configuration



### **BIOSTAR Memory Insight**



#### **DDR3-A1/B1/A2/B2 SPD Informations**

These items display SPD information of DDR3 memory.

## ***TA880GU3+ BIOS Manual***

---

---

### **Memory Clock Mode**

This item allows you to control the Memory Clock.  
Options: Auto (Default) / Limit / Manual

### **Memclock Value**

This item allows you to set the Memory Clock.  
Options: DDR3-800 (Default) / DDR3-1066 / DDR3-1333 / DDR3-1600 / Auto

### **DRAM Timing Mode**

This item allows you to choose to manually or automatically regulate the DRAM Timing.  
Options: Auto (Default) / DCT0 / DCT1 / Both

### **CAS Latency (CL)**

Options: Auto (Default) / 4~12 CLK

### **2T Command**

Options: Auto (Default) / 1T / 2T

### **TR CD**

Options: Auto (Default) / 5~12 CLK

### **TRP**

Options: Auto (Default) / 5~12 CLK

### **tR TP**

Options: Auto (Default) / 4~7 CLK

### **TR AS**

Options: Auto (Default) / 15~30 CLK

### **TRC**

Options: Auto (Default) / 11~42 CLK

## **TA880GU3+ BIOS Manual**

---

### **tWR**

Options: Auto (Default) / 5~8 / 10 / 12CLK

### **TR RD**

Options: Auto (Default) / 4~7 CLK


### **tWTR**

Options: Auto (Default) / 4~7 CLK

### **tRFC0 / tRFC1 / tRFC2 / tRFC3**

Options: Auto (Default) / 90ns / 110ns / 160ns / 300ns / 350ns

## **Memory Configuration**



### **Bank Interleaving**

Bank Interleaving is an advanced chipset technique used to improve memory performance. Memory interleaving increases bandwidth by allowing simultaneous access to more than one piece of memory.

Options: Auto (Default)

## **TA880GU3+ BIOS Manual**

---

---

### **Channel Interleaving**

This item allows you to control the DDR2 dual-channel function.

Options: XOR of Address bits [20:16, 6] (Default) / XOR of Address bits [20:16, 9] / Address bits 6 / Address bits 12 / Disabled

### **Enable Clock to AllDIMMs**

This item determines whether the BIOS should actively reduce EMI (Electromagnetic Interference) and reduce power consumption by turning off unoccupied or inactive DIMM slots.

Options: Disabled (Default) / Enabled

### **MemClk Tristate C3/ATLVID**

This item enables or disables the MemClk Tristate function in C3 Mode.

Options: Disabled (Default) / Enabled

### **Memory Hole Remapping**

This item allows you to enable or disable the remapping of the overlapped PCI memory above the total physical memory. Only 64-bit OS supports this function.

Options: Enabled (Default) / Disabled

### **DCT Unganged Mode**

This item controls the DRAM controller ganged (128bit\*1) / unganged (64bit\*2) dual-channel operation mode. If two DRAM modules with different size are installed, using unganged mode can still make it run in dual-channel operation.

Options: Always (Default) / Auto

### **Power Down Enable**

This item controls the DRAM power down function.

Options: Enabled (Default) / Disabled

### **Page Smashing**


This item is S/W Control of Page Smashing Mechanism.

Options: Disabled (Default) / IC / DC / Both

## TA880GU3+ BIOS Manual

---

### ECC Configuration



#### **ECC Mode**

This item allows you to select the DRAM ECC Mode.

Options: Disabled (Default) / Basic / Good / Super / Max / User

#### **DRAM ECC Enabled**

Options: Disabled (Default) / Enabled

#### **DRAM Scrub Redirect**

Options: Disabled (Default) / Enabled

#### **4-bit ECC Mode**

Options: Disabled (Default) / Enabled


#### **DRAM BG Scrub/Data Cache BG Scrub/L2 Cache BG Scrub/L3 Cache BG Scrub**

Options: Disabled (Default) / 40ns / 80ns / 160ns / 320ns / 640ns / 1.28us / 2.56us / 5.12us / 10.2us / 20.5us / 41.0us / 81.9us / 163.8us / 327.7us / 655.4us / 1.31ms / 2.62ms / 5.24ms / 10.49ms / 20.97ms / 42.00ms / 84.00ms

## ***TA880GU3+ BIOS Manual***

---

### **G.P.U Phase Control**



### **G.P.U Phase Mode**

This item allows you to control G.P.U Phase Mode (power saving technology).  
Options: Auto (Default) / Off

## **TA880GU3+ BIOS Manual**


---

### **Integrated Memory Test**

Integrated Memory Test allows users to test memory module compatibilities without additional device or software.


#### **Step 1:**

This item is disabled on default; change it to “Enable” to precede memory test.



#### **Step 2:**

When the process is done, change the setting back from “Enabled” to “Disabled” to complete the test.




## **TA880GU3+ BIOS Manual**

---

### **7 Exit Menu**

This menu allows you to load the optimal default settings, and save or discard the changes to the BIOS items.



#### **Save Changes and Exit**

Save all configuration changes to CMOS RAM and exit setup.

#### **Discard Changes and Exit**

Abandon all changes made during the current session and exit setup.

#### **Discard Changes**

Abandon all changes made during the current session and restore the previously saved values.

#### **Load Optimal Defaults**

This selection allows you to reload the BIOS when problem occurs during system booting sequence. These configurations are factory settings optimized for this system.

## **TA880GU3+ BIOS Manual**


---

### **CMOS Backup Function**

It allows users to save different CMOS settings into BIOS-ROM and reload any saved CMOS setting for customizing system configurations.


Moreover, users are able to save an ideal overclock setting during overclock operation.

There are 10 sets of record addresses in total, and users are able to name the CMOS data according to personal preference.



### **Security**

This sub-menu allows you to provide/revised supervisor and user password.



## **TA880GU3+ BIOS Manual**

---

---

### **Change Supervisor Password**

Setting the supervisor password will prohibit everyone except the supervisor from making changes using the CMOS Setup Utility. You will be prompted with to enter a password.

### **User Access Level**

This item allows supervisor to set the user level.

Options: Full Access (Default) / No Access / View Only / Limited

### **Change User Password**

If the Supervisor Password is not set, then the User Password will function in the same way as the Supervisor Password. If the Supervisor Password is set and the User Password is set, the “User” will only be able to view configurations but will not be able to change them.

### **Clear User Password**

This item is for clearing user password.

### **Password Check**

This item is for setting the timing that checking password.

Options: Setup (Default) / Always

### **Boot Sector Virus Protection**

This option allows you to choose the VIRUS Warning feature that is used to protect the IDE Hard Disk boot sector. If this function is enabled and an attempt is made to write to the boot sector, BIOS will display a warning message on the screen and sound an alarm beep.

Options: Disabled (Default) / Enabled