

FCC Information and Copyright

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation.

The vendor makes no representations or warranties with respect to the contents here and specially disclaims any implied warranties of merchantability or fitness for any purpose. Further the vendor reserves the right to revise this publication and to make changes to the contents here without obligation to notify any party beforehand.

Duplication of this publication, in part or in whole, is not allowed without first obtaining the vendor's approval in writing.

The content of this user's manual is subject to be changed without notice and we will not be responsible for any mistakes found in this user's manual. All the brand and product names are trademarks of their respective companies.



Dichiarazione di conformità sintetica

Ai sensi dell'art. 2 comma 3 del D.M. 275 del 30/10/2002

Si dichiara che questo prodotto è conforme alle normative vigenti e soddisfa i requisiti essenziali richiesti dalle direttive

2004/108/CE, 2006/95/CE e 1999/05/CE

quando ad esso applicabili

Short Declaration of conformity

We declare this product is complying with the laws in force and meeting all the essential requirements as specified by the directives

2004/108/CE, 2006/95/CE and 1999/05/CE

whenever these laws may be applied

Table of Contents

Chapter 1: Introduction	1
1.1 Before You Start	1
1.2 Package Checklist	1
1.3 Motherboard Features	2
1.4 Rear Panel Connectors	3
1.5 Motherboard Layout	4
Chapter 2: Hardware Installation	5
2.1 Installing Central Processing Unit (CPU)	5
2.2 FAN Headers	7
2.3 Installing System Memory	8
2.4 Connectors and Slots	10
Chapter 3: Headers & Jumpers Setup	14
3.1 How to Setup Jumpers	14
3.2 Detail Settings	14
Chapter 4: AMD DUAL Graphics Technology	20
4.1 AMD Dual Graphics Technology Introduction	20
4.2 AMD Dual Graphics Requirement	20
4.3 AMD Dual Graphics Setup	21
Chapter 5: RAID Functions	22
5.1 Operating System	22
5.2 Raid Arrays	22
5.3 How RAID Works	22
Chapter 6: UEFI BIOS & Software	26
6.1 UEFI BIOS	26
6.2 Software	29
6.3 BIOS Update	42
Chapter 7: Useful Help	47
7.1 Driver Installation Note	47
7.2 Extra Information	48
7.3 AMI BIOS Beep Code	49
7.4 AMI BIOS Post Code	49
7.5 Troubleshooting	51
Appendix: SPEC In Other Languages	52
Arabic	52
French	54
German	56
Italian	58
Japanese	60
Polish	62
Portuguese	64
Russian	66
Spanish	68

CHAPTER 1: INTRODUCTION

1.1 BEFORE YOU START

Thank you for choosing our product. Before you start installing the motherboard, please make sure you follow the instructions below:

- Prepare a dry and stable working environment with sufficient lighting.
- Always disconnect the computer from power outlet before operation.
- Before you take the motherboard out from anti-static bag, ground yourself properly by touching any safely grounded appliance, or use grounded wrist strap to remove the static charge.
- Avoid touching the components on motherboard or the rear side of the board unless necessary. Hold the board on the edge, do not try to bend or flex the board.
- Do not leave any unfastened small parts inside the case after installation. Loose parts will cause short circuits which may damage the equipment.
- Keep the computer from dangerous area, such as heat source, humid air and water.
- The operating temperatures of the computer should be 0 to 45 degrees Celsius.

1.2 PACKAGE CHECKLIST

- Serial ATA Cable x4
- Rear I/O Panel for ATX Case x1
- User's Manual x1
- Fully Setup Driver DVD x1
- CFX Bridge x1
- Calibration Microphone x1


Note: The package contents may be different due to the sales region or models in which it was sold. For more information about the standard package in your region, please contact your dealer or sales representative.

1.3 MOTHERBOARD FEATURES

Specifications	
CPU Support	Socket FM2 for AMD A-series/ E2-series processor Maximum CPU TDP (Thermal Design Power): 100Watt * Please refer to www.biostar.com.tw for CPU support list.
Chipset	AMD A85 FCH
Memory	Supports Dual Channel DDR3 800/ 1066/ 1333/ 1600/ 1866/ 2133(OC)/ 2400(OC) 4 x DDR3 DIMM Memory Slot, Max. Supports up to 64 GB Memory Each DIMM supports non-ECC 512MB/ 1/ 2/ 4/ 8/ 16 GB DDR3 module * Please refer to www.biostar.com.tw for Memory support list.
Storage	AMD A85 FCH 7x SATA 6Gb/s Connector Supports RAID 0,1,10,5 & AHCI
LAN	Realtek RTL 8111F 10/ 100/ 1000 Mb/s auto negotiation, Half / Full duplex capability
Audio Codec	ALC898 7.1 Channels, High Definition Audio, Biostar Hi-Fi
USB	4x USB 3.0 port (2 on rear I/Os and 2 via internal headers) 10x USB 2.0 port (4 on rear I/Os and 6 via internal headers)
Expansion Slots	1x PCI Slot 3x PCIe 2.0 x1 Slot 1x PCIe 2.0 x16 Slot (x4) 2x PCIe 2.0 x16 Slot (x16, x8), support AMD CrossFireX™ (x8, x8)
Rear I/Os	1x PS/2 Keyboard/ Mouse 1x HDMI Port 1x Display Port 1x VGA Port 1x DVI Port 1x eSATA 1x LAN port 4x USB 2.0 Port 2x USB 3.0 Port 6x Audio Jack
Internal I/Os	7x SATA 6.0Gb/s Connector 3x USB 2.0 Header (each header supports 2 USB 2.0 ports) 1x USB 3.0 Header (each header supports 2 USB 3.0 ports) 1x 8-Pin Power Connector 1x 24-Pin Power Connector 1x CPU Fan Connector 2x System Fan Connector 1x Front Panel Header 1x Front Audio Header 1x Clear CMOS Header 1x Consumer IR Header 1x Serial Port Header 1x S/PDIF out Connector

Specifications	
Form Factor	ATX Form Factor, 305mm x 244 mm
OS Support	Windows XP / Vista / 7/ 8 Biostar reserves the right to add or remove support for any OS with or without notice.


1.4 REAR PANEL CONNECTORS



- Note 1:** HDMI / DVI-D / VGA / DisplayPort output require an AMD family processor with integrated graphics.
- Note 2:** The mainboard supports three independent display outputs and the configurations can be HDMI+DisplayPort+DVI-D or HDMI+VGA+DVI-D
- Note 3:** Since the audio chip supports High Definition Audio Specification, the function of each audio jack can be defined by software. The input / output function of each audio jack listed above represents the default setting. However, when connecting external microphone to the audio port, please use the Line In (Blue) and Mic In (Pink) audio jack.
- Note 4:** Maximum resolution:

Outputs	Maximum resolution	Bit Depth
DisplayPort	4096 x 2160 @30Hz	18, 24, 30 bpp
HDMI	1920 x 1080 @60Hz	24, 30, 36 bpp
	1920 x 1200 @60Hz	24 bpp
DVI-D	1920 x 1200 @60Hz	30 bpp
	2560 x 1600 @60Hz	24 bpp
VGA	1920 x 1600 @60Hz	--


1.5 MOTHERBOARD LAYOUT




Note: ■ represents the 1st pin.

CHAPTER 2: HARDWARE INSTALLATION

2.1 INSTALLING CENTRAL PROCESSING UNIT (CPU)



Step 1: Pull the socket locking out from the socket and then raise the lever up to a 90-degree angle.




Step 2: Look for the white triangle on socket, and the gold triangle on CPU should point towards this white triangle. The CPU will fit only in the correct orientation.




Motherboard Manual

Step 3: Hold the CPU down firmly, and then close the lever to locked the position




Step 4: Put the CPU Fan on the CPU and buckle it. Connect the CPU FAN power cable to the CPU_FAN1. This completes the installation.




2.2 FAN HEADERS

These fan headers support cooling-fans built in the computer. The fan cable and connector may be different according to the fan manufacturer. Connect the fan cable to the connector while matching the black wire to pin#1.

CPU_FAN1: CPU Fan Header



SYS_FAN1/2: System Fan Header




Note:


CPU_FAN1, SYS_FAN1/2 support 4-pin and 3-pin head connectors. When connecting with wires onto connectors, please note that the red wire is the positive and should be connected to pin#2, and the black wire is Ground and should be connected to GND.

2.3 INSTALLING SYSTEM MEMORY


A. DDR3 Modules



1. Unlock a DIMM slot by pressing the retaining clips outward. Align a DIMM on the slot such that the notch on the DIMM matches the break on the slot.



2. Insert the DIMM vertically and firmly into the slot until the retaining chip snap back in place and the DIMM is properly seated.



Note:

If the DIMM does not go in smoothly, do not force it. Pull it all the way out and try again.

B. Memory Capacity

DIMM Socket Location	DDR3 Module	Total Memory Size
DDR3_A1	512MB/1GB/2GB/4GB/8GB/16GB	Max is 64GB.
DDR3_A2	512MB/1GB/2GB/4GB/8GB/16GB	
DDR3_B1	512MB/1GB/2GB/4GB/8GB/16GB	
DDR3_B2	512MB/1GB/2GB/4GB/8GB/16GB	

C. Dual Channel Memory Installation

Please refer to the following requirements to activate Dual Channel function:
Install memory module of the same density in pairs, shown in the table.

Dual Channel Status	DDR3_A1	DDR3_A2	DDR3_B1	DDR3_B2
Enabled	O	X	O	X
Enabled	X	O	X	O
Enabled	O	O	O	O

(O means memory installed, X means memory not installed.)

Note:

The DRAM bus width of the memory module must be the same (x8 or x16)

D. DDR Speed Support


Please refer to the following table for DDR speed reference: (x = 1 or 2)

# of DIMM per Channel	# of Ranks per DIMM	1.50V	1.35V	1.25V
1 of 2 UDIMMs	xR, 0	DDR3-1866	DDR3-1600	DDR3-1333
2 of 2 UDIMMs	1R, 1R	DDR3-1866	DDR3-1600	DDR3-1333
2 of 2 UDIMMs	2R, xR	DDR3-1600	DDR3-1333	DDR3-1066

2.4 CONNECTORS AND SLOTS

ATXPWR1: ATX Power Source Connector


This connector allows user to connect 24-pin power connector on the ATX power supply.



Pin	Assignment	Pin	Assignment
13	+3.3V	1	+3.3V
14	-12V	2	+3.3V
15	Ground	3	Ground
16	PS_ON	4	+5V
17	Ground	5	Ground
18	Ground	6	+5V
19	Ground	7	Ground
20	NC	8	PW_OK
21	+5V	9	Standby Voltage+5V
22	+5V	10	+12V
23	+5V	11	+12V
24	Ground	12	+3.3V

ATXPWR2: ATX Power Source Connector

These connectors provide +12V to CPU power circuit. If the CPU power plug is 4-pin, please plug it into Pin 1-2-5-6 of ATXPWR2.




Note1: Before you power on the system, please make sure that both ATXPWR1 and ATXPWR2 connectors have been plugged-in.

Note2: Insufficient power supplied to the system may result in instability or the peripherals not functioning properly. Use of a PSU with a higher power output is recommended when configuring a system with more power-consuming devices.


PCI1: Peripheral Component Interconnect Slot

This motherboard is equipped with 1 standard PCI slot. PCI stands for Peripheral Component Interconnect, and it is a bus standard for expansion cards.



PEX1_1/1_2/1_3: PCI-Express Gen2 x1 Slot

- PCI-Express 2.0 compliant.
- Data transfer bandwidth up to 500MB/s per direction; 1GB/s in total




**PEX16_1/ PEX16_2: PCI-Express Gen2 x16 (x16 / x8)
(AMD CrossFireX) Slots**

- PCI-Express 2.0 compliant.
- Maximum theoretical realized bandwidth of 8GB/s simultaneously per direction, for an aggregate of 16GB/s totally.
- The speed of PEX16_1 is x16 or x8 when CFX is enabled. The speed of PEX16_2 is x8.

Note: For more details about AMD CrossFireX, please access the website, respectively:
<http://support.amd.com/us/Pages/AMDSupportHub.aspx> .


PEX16_3: PCI-Express Gen2 x4 Slot

- PCI-Express 2.0 compliant.
- Maximum theoretical realized bandwidth of 2GB/s simultaneously per direction, for an aggregate of 4GB/s totally.



SATA1~SATA4: Serial ATA 6.0 Gb/s Connectors

These connectors connect to SATA hard disk drives via SATA cables.



Pin	Assignment
1	Ground
2	TX+
3	TX-
4	Ground
5	RX-
6	RX+
7	Ground

CHAPTER 3: HEADERS & JUMPERS SETUP

3.1 HOW TO SETUP JUMPERS


The illustration shows how to set up jumpers. When the jumper cap is placed on pins, the jumper is “close”, if not, that means the jumper is “open”.



3.2 DETAIL SETTINGS

PANEL1: Front Panel Header


This 16-pin connector includes Power-on, Reset, HDD LED, Power LED, and speaker connection. It allows user to connect the PC case’s front panel switch functions.



Pin	Assignment	Function	Pin	Assignment	Function
1	+5V	Speaker Connector	9	N/A	N/A
2	N/A		10	N/A	
3	N/A		11	N/A	
4	Speaker	Hard drive LED	12	Power LED (+)	Power LED
5	HDD LED (+)		13	Power LED (+)	
6	HDD LED (-)	Reset button	14	Power LED (-)	
7	Ground		15	Power button	Power-on button
8	Reset control	16	Ground		

JFRONT_USB3_1: Header for USB 3.0 Ports at Front Panel


This header allows user to connect additional USB cable on the PC front panel, and also can be connected with a wide range of simultaneously accessible external Plug and Play peripherals.



Pin	Assignment	Pin	Assignment
1	VBUS0	11	D2+
2	SSRX1-	12	D2-
3	SSRX1+	13	Ground
4	Ground	14	SSTX2+
5	SSTX1-	15	SSTX2-
6	SSTX1+	16	Ground
7	Ground	17	SSRX2+
8	D1-	18	SSRX2-
9	D1+	19	VBUS1
10	ID	20	Key

F_USB1/2/3: Headers for USB 2.0 Ports at Front Panel


This header allows user to connect additional USB cable on the PC front panel, and also can be connected with a wide range of simultaneously accessible external Plug and Play peripherals.



Pin	Assignment
1	+5V (fused)
2	+5V (fused)
3	USB-
4	USB-
5	USB+
6	USB+
7	Ground
8	Ground
9	NC
10	Key

F_AUDIO1: Front Panel Audio Header

This header allows user to connect the front audio output cable with the PC front panel. This header supports HD and AC'97 audio front panel connector.




HD Audio		AC'97	
Pin	Assignment	Pin	Assignment
1	Mic Left in	1	Mic In
2	Ground	2	Ground
3	Mic Right in	3	Mic Power
4	GPIO	4	Audio Power
5	Right line in	5	RT Line Out
6	Jack Sense	6	RT Line Out
7	Front Sense	7	Reserved
8	Key	8	Key
9	Left line in	9	LFT Line Out
10	Jack Sense	10	LFT Line Out

Note1: It is recommended that you connect a high-definition front panel audio module to this connector to avail of the motherboard's high definition audio capability.

Note2: Please try to disable the "Front Panel Jack Detection" if you want to use an AC'97 front audio output cable. The function can be found via O.S. Audio Utility.

JSPDIFOUT1: Digital Audio-out Connectors


The JSPDIFOUT1 is for connecting the PCI bracket SPDIF output.



Pin	Assignment
1	+5V
2	SPDIF_OUT
3	Ground

JCMOS1: Clear CMOS Header

Placing the jumper on pin2-3, it allows user to restore the BIOS safe setting and the CMOS data. Please carefully follow the procedures to avoid damaging the motherboard.



Pin 1-2 Close:
Normal Operation (default).




Pin 2-3 Close:
Clear CMOS data.

※ Clear CMOS Procedures:

1. Remove AC power line.
2. Set the jumper to "Pin 2-3 close".
3. Wait for five seconds.
4. Set the jumper to "Pin 1-2 close".
5. Power on the AC.
6. Load Optimal Defaults and save settings in CMOS.

J_COM1: Serial Port Connector


The motherboard has a Serial Port Connector for connecting RS-232 Port.




Pin	Assignment
1	Carrier detect
2	Received data
3	Transmitted data
4	Data terminal ready
5	Signal ground
6	Data set ready
7	Request to send
8	Clear to send
9	Ring indicator
10	NC

CIR1: Consumer IR Connector

This header is for infrared remote control and communication.





Pin	Assignment
1	IrDA serial input
2	Ground
3	Ground
4	Key
5	IrDA serial output
6	IR Power




BIOS POST Code/CPU Temperature Indicator

This indicator will show POST code while booting. After the booting sequence, it will show current CPU temperature. Please refer to Chapter 7.4 for all the BIOS POST codes.



On-Board Buttons

There are 4 on-board buttons.



SW_PWR1:

This is an on-board Power Switch button.

SW_RST1:

This is an on-board Reset button. The led will blink when reading or writing to the HDDs.

SW_CLR1:

This is an on-board Clear CMOS button. Press the button 1~2 seconds to load the BIOS defaults.

SW_OV1:

This is an on-board O.C. Switch button which is used for automatic overlocking.

To Enable O.C.: Press the button once while the system is off. The button will be locked and remain in a depressed position until it is pressed again. After reboot, the CPU will be O.C. automatically to optimal performance value.

To Disable O.C.: Power off the system and press the button again. The button will be released from the depressed position and the CPU configuration will go back to your original settings.

CHAPTER 4: AMD DUAL GRAPHICS TECHNOLOGY

4.1 AMD DUAL GRAPHICS TECHNOLOGY INTRODUCTION

When user adds a PCIE display adapter, it can be integrated with IGD to show better performance. To make the two video devices work simultaneously and normally, please refer to the following setting.

4.2 AMD DUAL GRAPHICS REQUIREMENT

- Operating System: Windows Vista / Windows 7 / Windows 8
- Supported Dual Graphics Combinations:

AMD Radeon™ Graphics Card	A10-Series HD 7660D	A8-Series HD7560D	A6-Series HD 7540D
HD 6670	●	●	
HD 6570	●	●	●
HD 6450			●

● Recommended graphics cards for AMD dual-graphics

Note 1: A4-Series products do not support Dual Graphics.

Note 2: The information described above in this manual is for your reference only and the actual information and settings on board may be different from this manual. For further AMD Dual Graphics information, please visit the following website: <http://www.amd.com>


4.3 AMD DUAL GRAPHICS SETUP

Step 1: Insert Dual Graphics-Ready graphics card into PEX16_1 slot.

Step 2: Set the BIOS setting as follows:
 [Chipset]→[North Bridge]→[Surround View]→[Enabled]



Step 3: Install Driver DVD Chipset Driver, and reboot the system. Activate AMD VISION Engine Control Center to make sure CrossFire has been enabled.



CHAPTER 5: RAID FUNCTIONS

5.1 OPERATING SYSTEM

Supports Windows Vista, Windows 7 and Windows 8

5.2 RAID ARRAYS

RAID supports the following types of RAID arrays:

RAID 0: RAID 0 defines a disk striping scheme that improves disk read and write times for many applications.

RAID 1: RAID 1 defines techniques for mirroring data.

RAID 10: RAID 10 combines the techniques used in RAID 0 and RAID 1.

RAID 5: RAID 5 provides fault tolerance and better utilization of disk capacity.


5.3 How RAID WORKS

RAID 0:

The controller “stripes” data across multiple drives in a RAID 0 array system. It breaks up a large file into smaller blocks and performs disk reads and writes across multiple drives in parallel. The size of each block is determined by the stripe size parameter, which you set during the creation of the RAID set based on the system environment. This technique reduces overall disk access time and offers high bandwidth.

Features and Benefits

- **Drives:** Minimum 2, and maximum is up to 6 or 8. Depending on the platform.
- **Uses:** Intended for non-critical data requiring high data throughput, or any environment that does not require fault tolerance.
- **Benefits:** provides increased data throughput, especially for large files. No capacity loss penalty for parity.
- **Drawbacks:** Does not deliver any fault tolerance. If any drive in the array fails, all data is lost.
- **Fault Tolerance:** No.
- **Total Capacity:** (Minimal. HDD Capacity) x (Connected HDDs Amount)




RAID 1:

Every read and write is actually carried out in parallel across 2 disk drives in a RAID 1 array system. The mirrored (backup) copy of the data can reside on the same disk or on a second redundant drive in the array. RAID 1 provides a hot-standby copy of data if the active volume or drive is corrupted or becomes unavailable because of a hardware failure.

RAID techniques can be applied for high-availability solutions, or as a form of automatic backup that eliminates tedious manual backups to more expensive and less reliable media.

Features and Benefits

- **Drives:** Minimum 2, and maximum is 2.
- **Uses:** RAID 1 is ideal for small databases or any other application that requires fault tolerance and minimal capacity.
- **Benefits:** Provides 100% data redundancy. Should one drive fail, the controller switches to the other drive.
- **Drawbacks:** Requires 2 drives for the storage space of one drive. Performance is impaired during drive rebuilds.
- **Fault Tolerance:** Yes.




RAID 10:

RAID 1 drives can be striped using RAID 0 techniques. Resulting in a RAID 10 solution for improved resiliency, performance and rebuild performance.

Features and Benefits

- **Drives:** Minimum 4, and maximum is 6 or 8, depending on the platform.
- **Benefits:** Optimizes for both fault tolerance and performance, allowing for automatic redundancy. May be simultaneously used with other RAID levels in an array, and allows for spare disks.
- **Drawbacks:** Requires twice the available disk space for data redundancy, the same as RAID level 1.
- **Fault Tolerance:** Yes.




RAID 5:

RAID 5 stripes both data and parity information across three or more drives. It writes data and parity blocks across all the drives in the array. Fault tolerance is maintained by ensuring that the parity information for any given block of data is placed on a different drive from those used to store the data itself.

Features and Benefits

- **Drives:** Minimum 3.
- **Uses:** RAID 5 is recommended for transaction processing and general purpose service.
- **Benefits:** An ideal combination of good performance, good fault tolerance, and high capacity and storage efficiency.
- **Drawbacks:** Individual block data transfer rate same as a single disk. Write performance can be CPU intensive.
- **Fault Tolerance:** Yes.



CHAPTER 6: UEFI BIOS & SOFTWARE

6.1 UEFI BIOS

UEFI BIOS Features

- Overclocking Navigator Engine (O.N.E.)
- Self Recovery System (S.R.S)
- Smart Fan Function
- BIO-Flasher: Update UEFI BIOS file from USB Flash Drive

!! WARNING !!

For better system performance, the UEFI BIOS firmware is being continuously updated. The UEFI BIOS information described below in this manual is for your reference only and the actual UEFI BIOS information and settings on board may be different from this manual. For further information of setting up the UEFI BIOS, please refer to the UEFI BIOS Manual in the Setup DVD.

A. Overclocking Navigator Engine (O.N.E.)

O.N.E provides 4 systems allowing users to customize personal overclock settings: Manual Voltage System, Manual Memory System, Manual MCT System, and Manual G.P.U System.



Note:

Not all types of CPU perform above overclock setting ideally; the difference will be based on the selected CPU model.

Note:

Overclock is an optional process, but not a “must-do” process; it is not recommended for inexperienced users. Therefore, we will not be responsible for any hardware damage which may be caused by overclocking. We also would not guarantee any overclocking performance.

B. Self Recovery System (S.R.S.)

This function can't be seen under UEFI BIOS setup, and is always on whenever the system starts up.

However, it can prevent system hang-up due to inappropriate overclock actions.

When the system hangs up, S.R.S. will automatically log in the default UEFI BIOS setting, and all overclock settings will be re-configured.

C. Smart Fan Function

Smart Fan Function is under “Smart Fan Control” in “Advanced Menu”.

This is a brilliant feature to control CPU/System Temperature vs. Fan speed. When enabling Smart Fan function, Fan speed is controlled automatically by CPU/System temperature.

This function will protect CPU/System from overheat problem and maintain the system temperature at a safe level.





CPU Smart FAN

This item allows you to control the CPU Smart Fan function.

CPU FAN Calibrate

Press [ENTER] to calibrate CPU FAN.

Control Mode

This item provides several operation modes of the fan.

Fan Ctrl OFF(°C)

When CPU temperature is lower than this value, the CPU fan will keep lowest RPM. The range is from 0~50, with an interval of 1.

Fan Ctrl On(°C)

When CPU temperature is higher than this value, the CPU fan controller will turn on. The range is from 0~70, with an interval of 1.

Fan Ctrl Start Value

This item sets CPU FAN Start Speed Value. The range is from 0~255, with an interval of 1.

Fan Ctrl Sensitive

The bigger the numeral is, the higher the FAN speed is. The range is from 1~255, with an interval of 1.

6.2 SOFTWARE

Installing Software


1. Insert the Setup DVD to the optical drive. The driver installation program would appear if the Auto-run function has been enabled.
2. Select **Software Installation**, and then click on the respective software title.
3. Follow the on-screen instructions to complete the installation.

Launching Software

After the installation process is completed, you will see the software icon showing on the desktop. Double-click the icon to launch it.

TOverclocker

TOverclocker presents a simple Windows-based system performance enhancement and manageability utility. It features several powerful and easy to use tools such as Overclocking for enhancing system performance, also for special enhancement on CPU and Memory. Smart-Fan management and PC health are for monitoring system status. This utility also allows you to make overclocking profiles saving unlimitedly, and pre-set OC modes are for easy OC. (The screenshot below is for reference only)



Motherboard Manual



The **CPU** tab provides information on the CPU and motherboard.



The **Memory** tab provides information on the memory module(s).


You can select memory module on a specific slot to see its information.



The **OC Tweaker** tab allows you to change system clock settings and voltages settings. It also provides six pre-set modes for you: (The screenshot below is for reference only)



Six Pre-set Modes: V3, V6, V9, V12, V15, AUTO for different overclocking experience. (The screenshot below is for reference only)



The **HW Monitor** tab allows you to monitor hardware voltage, fan speed, and temperature. Besides, you also can set related values for CPU Smart Fan. (The screenshot below is for reference only)






Pressing **TOVERCLOCKER** logo will display information about manufacturer and software version. You can update current version by clicking the button "Live Update."



Green Power II Utility

BIOSTAR G.P.U II (Green Power Utility) is a new function. The utility enhances energy efficiency by disabling extra phases while CPU is on light loading; it features 4+1 power phases, current power saving, and total power saving. This tool integrates a friendly GUI to monitor your CPU Usage, CPU Watt, and CPU Temperature. Moreover, it optimizes power saving and best power efficiency on your system. (The illustration below is for reference only)



G.P.U Mode Setting

This utility provides five modes, upon your requirements, to improve system performance or to save power consumption.

Note:

Even if the modes saving more power consumption are chosen, the system still can keep excellent performance.

■ **Auto Phase Mode**

System switches the mode automatically according to current system loading condition.

■ **Performance Mode**

This is the mode saving power consumption most. Least energy will be used in the system.

■ **Typical Mode**

Compared with that in Performance Mode, energy consumption in this mode is a little bit more.

■ **Medium Mode**


This is the standard system power saving mode.

■ **Maxi-Energy Mode**

This is the best system performance mode.

Smart EAR

Smart EAR is a windows-based audio utility which allows you to easily adjust system volume. With its user-friendly GUI, you can also adjust impedance setting (Low/High Gain) to optimize your headphone performance.



- **High/Low Gain Switch:** Keep the gain switch to low for low impedance headphone and set to high for high impedance headphone.
- **Mute Button:** To disable system sound
- **Volume Control Knob:** The volume can be finely adjusted by turning the knob either clockwise or anti-clockwise to increase or decrease system volume accordingly.
- **Information Button:** Get information of the application
- **Minimize Button:** Minimize the application window to the taskbar
- **Exit Button:** Exit the application

Note:


1. Smart EAR is only supported by Windows 7 and BIOSTAR Hi-Fi series motherboards.
2. High/Low Gain Switch is only for "Front Panel Audio Header", please make sure you are connecting your headphone to the front panel I/O.

Multi Channels Calibration (MCC)

Multi Channels Calibration (MCC) can transform any room into the ideal listening environment. With Multi Channels Calibration (MCC), audio performance is automatically calibrated according to the dimensions of your room.

Take a note of following precautions before you start the calibration.

1. Do not connect or disconnect the speaker setup microphone and speakers during the calibration.
2. Do not stand between the speakers and microphone, and avoid obstacles blocking the path between speakers and microphone.
3. Turn off all media players and do not adjust any audio settings (ex. volume or mute) in your operating system.
4. MCC software is only supported by Windows 7 and BIOSTAR Hi-Fi series motherboards.



- **Status Panel:** Show the information of speakers and listening positions.
- **Midnight Mode:** Turn on this function will let you enjoy a movie quietly without compromising sound qualities, surround effects and dialogue clarity.
- **Calibration Button:** Start or stop the calibration.
- **Channel Output Buttons:** Select the channel output (2/ 4/ 5.1/ 7.1-channel)
- **Listening Position Buttons:** It allows you setup five listening positions.
- **Speaker Volume:** Show each speaker's volume.
- **Information Button:** Get information of the application.
- **Minimize Button:** Minimize the application window to the taskbar.
- **Exit Button:** Exit the application.

Motherboard Manual

Start the Calibration:

Step 1:

Install and launch Multi Channels Calibration software

Step 2:

Arrange and connect the speakers in your room.

Step 3:

Select the channel output (2/ 4/ 5.1/ 7.1-channel) for the speak configuration.

Step 4:

Place the speaker setup microphone at ear height of a seated listener in your room and connection it to Mic In jack.

Note:

To setup 5.1-channel for a motherboard with 3 audio jacks, please connect the speaker setup microphone to front panel Mic-In.

Step 5:

Select your preferred listening position and click the “Listening Position Button”.

Step 6:

Click the “Calibration Button”. You can see a notice window then click “Next” to start the calibration. The test tone will be played through each speakers and it will take 2-3 minutes to process the calibration. Please make the room as quiet as possible at the meantime.

Step 7:

After completing calibration, you will see a finish window then click “OK” to exit this calibration.

Audio Ports:

For the definition of each audio port, please refer to the table below:

The 2/ 4/ 5.1-channel configuration for 3 audio jacks

Port	2-channel	4-channel	5.1 channel
Blue	Line In	Rear Speaker Out	Rear Speaker Out
Green	Line Out	Front Speaker Out	Front Speaker Out
Pink	Mic In	Mic In	Center/Subwoofer Out

The 2/ 4/ 5.1/ 7.1-channel configuration for 6 audio jacks

Port	2-channel	4-channel	5.1 channel	7.1 channel
Blue	Line In	Line In	Line In	Line In
Green	Line Out	Front Speaker Out	Front Speaker Out	Front Speaker Out
Pink	Mic In	Mic In	Mic In	Mic In
Orange	--	--	Center/Subwoofer Out	Center/Subwoofer Out
Black	N/A	Rear Speaker Out	Rear Speaker Out	Rear Speaker Out
Grey	--	--	--	Side Speaker Out

Guide of Lucid VIRTU MVP Installation

With Lucid VIRTU MVP solution, the resource and performance of graphics can be integrated so that user can choose the suitable mode for the requirement.

System Requirements

- **CPU:** CPU with integrated graphics support
- **Chipset:** Any chipset with integrated graphics output
- **Discrete GPU:** Any Nvidia/AMD GPU with DX9/DX10/DX11 support
- **Memory Size:** 2GB
- **Operating System:** Windows 7/8 32-bit and 64-bit
- **Hard Disk Space:** 20MB

BIOS Setting

Please try to set Onboard VGA (IGD) as first display if you want to use the i-mode.

i-Mode & d-Mode

1. **i-Mode:** i-Mode provides user with near zero performance overhead on 3D graphics games, Virtual VSync and Hyperformance features, integrated GPU special features and power saving options when no 3D gaming is used. To use Lucid VIRTU Universal MVP solution in i-Mode, display must be always connected to motherboard video output.

2. **d-Mode:** d-Mode is provided for demanding 3D gamers to achieve uncompromised 3D performance of discrete GPU installed in the system, along with Virtual VSync and Hyperformance quality/performance improvement features. In this mode, Virtu Universal MVP allows user to utilize integrated GPU special features such as transcoding, while display is connected to discrete GPU.

Note1: In most cases the differences of 3D performance between i-Mode and d-Mode are unnoticeable to the user, so it is recommended to use i-mode to save power.

Note2: To use Lucid VIRTU Universal MVP solution in d-Mode, display must be connected to discrete GPU installed in the system.

Motherboard Manual

Software Installation

1. Install VGA Driver and VIRTU MVP Software.



2. If for some reason auto-activation process fails, or the internet is not available for 30 days, user will have to manually activate Virtu Universal MVP by pressing “**Activate**” button through the Internet.

3. When Virtu Universal MVP successfully activates, the screen will look like this.



4. After installation, please restart the computer. The left screenshot is control panel.

eHot-Line (Optional)


eHot-Line is a convenient utility that helps you to contact with our Tech-Support system. This utility will collect the system information which is useful for analyzing the problem you may have encountered, and then send these information to our tech-support department to help you fix the problem.

 Before you use this utility, please set Outlook Express as your default e-mail client application program.

*represents important information that you must provide. Without this information, you may not be able to send out the mail.

This block will show the information which would be collected in the mail.

* Describe condition of your system.



* Select your area or the area close to you.

Provide the e-mail address that you would like to send the copy to.

* Provide the name of the memory module manufacturer.

Provide the name of the power supply manufacturer and the model no.

Send the mail out.

Exit this dialog.


Save these information to a .txt file

After filling up this information, click **“Send”** to send the mail out. A warning dialog would appear asking for your confirmation; click **“Send”** to confirm or **“Do Not Send”** to cancel.



If you want to save this information to a .txt file, click **“Save As...”** and then you will see a saving dialog appears asking you to enter file name.

Enter the file name and then click “Save”. Your system information will be saved to a .txt file.



Open the saved .txt file, you will see your system information including motherboard/BIOS/CPU/video/device/OS information. This information is also concluded in the sent mail.



We will not share customer’s data with any other third parties, so please feel free to provide your system information while using eHot-Line service.



If you are not using Outlook Express as your default e-mail client application, you may need to save the system information to a .txt file and send the file to our tech support with other e-mail application. Go to the following web <http://www.biostar.com.tw/app/en/about/contact.php> for getting our contact information.

BIOScreen Utility (Optional)

This utility allows you to personalize your boot logo easily. You can choose BMP as your boot logo so as to customize your computer.



Please follow the following instructions to update boot logo:

1. **Load Image** : Choose the picture as the boot logo.
2. **Transform** : Transform the picture for BIOS and preview the result.
3. **Update Bios** : Write the picture to BIOS Memory to complete the update.

6.3 BIOS UPDATE

There are three ways to update the BIOS:
BIOS Update Utility, BIOS Online Update Utility and BIOS Flasher.


1. BIOS Update Utility

1. Installing BIOS Update Utility from the DVD Driver.
2. Download the proper BIOS from www.biostar.com.tw.


3. Open BIOS Update Utility and click the **Update BIOS** button on the main screen.




4. A warning message will show up to request your agreement to start the BIOS update. Click **OK** to start the update procedure.



5. Choose the location for your BIOS file in the system. Please select the proper BIOS file, and then click on **Open**. It will take several minutes, please be patient.



6. After the BIOS Update process is finished, click on **OK** to reboot the system.




7. While the system boots up and the full screen logo shows up, please press the **Del** <Delete> key to enter BIOS setup.

After entering the BIOS setup, please go to the **Save & Exit**, using the **Restore Defaults** function to load Optimized Defaults, and select **Save Changes and Reset** to restart the computer. Then, the BIOS Update is completed.

Backup BIOS

Click the Backup BIOS button on the main screen for the backup of BIOS, and select a proper location for your backup BIOS file in the system, and click **Save**.




2. Online Update Utility

1. Installing BIOS Update Utility from the DVD Driver.
2. Please make sure the system is connected to the internet before using this function.


3. Open BIOS Update Utility and click the **Online Update** button on the main screen.




4. An open dialog will show up to request your agreement to start the BIOS update. Click **Yes** to start the online update procedure.




5. If there is a new BIOS version, the utility will ask you to download it. Click **Yes** to proceed.




6. After the download is completed, you will be asked to program (update) the BIOS or not. Click **Yes** to proceed.



7. After the updating process is finished, you will be asked you to reboot the system. Click **OK** to reboot.



8. While the system boots up and the full screen logo shows up, press  <Delete> key to enter BIOS setup.

After entering the BIOS setup, please go to the **Save & Exit**, using the **Restore Defaults** function to load Optimized Defaults, and select **Save Changes and Reset** to restart the computer. Then, the BIOS Update is completed.

3. BIOSTAR BIOS Flasher

BIOSTAR BIOS Flasher is a BIOS flashing utility providing you an easy and simple way to update your BIOS via USB pen drive.



- This utility only allows storage device with FAT32/16 format and single partition.
- Shutting down or resetting the system while updating the BIOS will lead to system boot failure.

The BIOSTAR BIOS Flasher is built in the BIOS ROM. To enter the utility, **press <F12> during the Power-On Self Tests (POST) procedure** while booting up.

Updating BIOS with BIOSTAR BIOS Flasher

1. Go to the website to download the latest BIOS file for the motherboard.
2. Then, copy and save the BIOS file into a USB flash (pen) drive.
3. Insert the USB pen drive that contains the BIOS file to the USB port.
4. Power on or reset the computer and then press **<F12>** during the **POST** process.

5. After entering the POST screen, the BIOS-FLASHER utility pops out. Choose [fs0] to search for the BIOS file.




6. Select the proper BIOS file, and a message asking if you are sure to flash the BIOS file. Click Yes to start updating BIOS.



7. A dialog pops out after BIOS flash is completed, asking you to restart the system. Press the [Y] key to restart system.



8. While the system boots up and the full screen logo shows up, press  <Delete> key to enter BIOS setup.

After entering the BIOS setup, please go to the **Save & Exit**, using the **Restore Defaults** function to load Optimized Defaults, and select **Save Changes and Reset** to restart the computer. Then, the BIOS Update is completed.




All the information and content above about software are subject to be changed without notice. For better performance, the software is being continuously updated. The information and pictures described above are for your reference only. The actual information and settings on board may be slightly different from this manual.

CHAPTER 7: USEFUL HELP

7.1 DRIVER INSTALLATION NOTE

After you installed your operating system, please insert the Fully Setup Driver DVD into your optical drive and install the driver for better system performance.

You will see the following window after you insert the DVD



The setup guide will auto detect your motherboard and operating system.

Note:

If this window didn't show up after you insert the Driver DVD, please use file browser to locate and execute the file SETUP.EXE under your optical drive.

A. Driver Installation

To install the driver, please click on the Driver icon. The setup guide will list the compatible driver for your motherboard and operating system. Click on each device driver to launch the installation program.

B. Software Installation

To install the software, please click on the Software icon. The setup guide will list the software available for your system, click on each software title to launch the installation program.

C. Manual

Aside from the paperback manual, we also provide manual in the Driver DVD. Click on the Manual icon to browse for available manual.

Note:

You will need Acrobat Reader to open the manual file. Please download the latest version of Acrobat Reader software from <http://get.adobe.com/reader/>

7.2 EXTRA INFORMATION

CPU Overheated

If the system shutdown automatically after power on system for seconds, that means the CPU protection function has been activated.

When the CPU is over heated, the motherboard will shutdown automatically to avoid a damage of the CPU, and the system may not power on again.

In this case, please double check:

1. The CPU cooler surface is placed evenly with the CPU surface.
2. CPU fan is rotated normally.
3. CPU fan speed is fulfilling with the CPU speed.

After confirmed, please follow steps below to relief the CPU protection function.

1. Remove the power cord from power supply for seconds.
2. Wait for seconds.
3. Plug in the power cord and boot up the system.

Or you can:

1. Clear the CMOS data.
(See "Close CMOS Header: JCMOS1" section)
2. Wait for seconds.
3. Power on the system again.

7.3 AMI BIOS BEEP CODE

Boot Block Beep Codes

Number of Beeps	Description
Continuing	Memory sizing error or Memory module not found

POST BIOS Beep Codes

Number of Beeps	Description
1	Success booting.
8	Display memory error (system video adapter)

7.4 AMI BIOS POST CODE

Code	Description
10	PEI Core is started
11	Pre-memory CPU initialization is started
15	Pre-memory North Bridge initialization is started
19	Pre-memory South Bridge initialization is started
2B	Memory initialization. Serial Presence Detect (SPD) data reading
2C	Memory initialization. Memory presence detection
2D	Memory initialization. Programming memory timing information
2E	Memory initialization. Configuring memory
2F	Memory initialization (other).
31	Memory Installed
32	CPU post-memory initialization is started
33	CPU post-memory initialization. Cache initialization
34	CPU post-memory initialization. Application Processor(s) (AP) initialization
35	CPU post-memory initialization. Boot Strap Processor (BSP) selection
36	CPU post-memory initialization. System Management Mode (SMM) initialization
37	Post-Memory North Bridge initialization is started
3B	Post-Memory North Bridge initialization (North Bridge module specific)
4F	DXE IPL is started
60	DXE Core is started
F0	Recovery condition triggered by firmware (Auto recovery)
F1	Recovery condition triggered by user (Forced recovery)
F2	Recovery process started
F3	Recovery firmware image is found
F4	Recovery firmware image is loaded
E0	S3 Resume is started (S3 Resume PPI is called by the DXE IPL)
E1	S3 Boot Script execution
E2	Video repost
E3	OS S3 wake vector call
60	DXE Core is started
61	NVRAM initialization
62	Installation of the South Bridge Runtime Services
63	CPU DXE initialization is started
68	PCI host bridge initialization
69	North Bridge DXE initialization is started
6A	North Bridge DXE SMM initialization is started
70	South Bridge DXE initialization is started

Motherboard Manual

Code	Description
71	South Bridge DXE SMM initialization is started
72	South Bridge devices initialization
78	South Bridge DXE Initialization (South Bridge module specific)
79	ACPI module initialization
90	Boot Device Selection (BDS) phase is started
91	Driver connecting is started
92	PCI Bus initialization is started
93	PCI Bus Hot Plug Controller Initialization
94	PCI Bus Enumeration
95	PCI Bus Request Resources
96	PCI Bus Assign Resources
97	Console Output devices connect
98	Console input devices connect
99	Super IO Initialization
9A	USB initialization is started
9B	USB Reset
9C	USB Detect
9D	USB Enable
A0	IDE initialization is started
A1	IDE Reset
A2	IDE Detect
A3	IDE Enable
A4	SCSI initialization is started
A5	SCSI Reset
A6	SCSI Detect
A7	SCSI Enable
A8	Setup Verifying Password
A9	Start of Setup
AB	Setup Input Wait
AD	Ready To Boot event
AE	Legacy Boot event
AF	Exit Boot Services event
B0	Runtime Set Virtual Address MAP Begin
B1	Runtime Set Virtual Address MAP End
B2	Legacy Option ROM Initialization
B3	System Reset
B4	USB hot plug
B5	PCI bus hot plug
B6	Clean-up of NVRAM
B7	Configuration Reset (reset of NVRAM settings)

7.5 TROUBLESHOOTING

Probable	Solution
<ol style="list-style-type: none"> 1. There is no power in the system. Power LED does not shine; the fan of the power supply does not work 2. Indicator light on keyboard does not shine. 	<ol style="list-style-type: none"> 1. Make sure power cable is securely plugged in. 2. Replace cable. 3. Contact technical support.
<p>System is inoperative. Keyboard lights are on, power indicator lights are lit, and hard drives are running.</p>	<p>Using even pressure on both ends of the DIMM, press down firmly until the module snaps into place.</p>
<p>System does not boot from a hard disk drive, but can be booted from optical drive.</p>	<ol style="list-style-type: none"> 1. Check cable running from disk to disk controller board. Make sure both ends are securely plugged in; check the drive type in the standard CMOS setup. 2. Backing up the hard drive is extremely important. All hard disks are capable of breaking down at any time.
<p>System only boots from an optical drive. Hard disks can be read, applications can be used, but system fails to boot from a hard disk.</p>	<ol style="list-style-type: none"> 1. Back up data and applications files. 2. Reformat the hard drive. Re-install applications and data using backup disks.
<p>Screen message shows "Invalid Configuration" or "CMOS Failure."</p>	<p>Review system's equipment. Make sure correct information is in setup.</p>
<p>System cannot boot after user installs a second hard drive.</p>	<ol style="list-style-type: none"> 1. Set master/slave jumpers correctly. 2. Run SETUP program and select correct drive types. Call the drive manufacturers for compatibility with other drives.

APPENDIX: SPEC IN OTHER LANGUAGES

ARABIC

المواصفات	
المأخذ 2 FM لمعالج ايه إم دي AMD تسلسل A / تسلسل E 2 الحد الأقصى للطاقة الحرارية في تصميم المعالج (thermal design power – TDP): 100 واط. * يرجى الرجوع إلى الموقع www.biostar.com.tw لقائمة دعم المعالج CPU.	قاعدة وحدة المعالجة المركزية
ايه إم دي FCH A85 AMD تدعم قناة مزدوجة دي. دي. ار. DDR3 800 / 1066 / 1333 / 1600 / 1866 / 2133(OC) / 2400(OC) 4x دي. دي. ار. DDR3 فتحات الذاكرة المزدوجة DIMM، تتحمل كحد أقصى 64 جيجابايت ذاكرة كل فتحة مزدوجة DIMM تتحمل دون ECC 512 ميجا بايت / 16/8/4/2/1 جيجابايت دي. دي. ار. DDR3 * يرجى الرجوع إلى الموقع www.biostar.com.tw لقائمة دعم الذاكرة.	مجموعة الشرائح الذاكرة
ايه إم دي FCH A85 AMD : وصلة x 7 ساتا SATA 6 جيجا بايت / الثانية تتحمّل رايد RAID 10 / 5 / 1 / 0	التخزين
ريالتيك رت ل REALTEK RTL 8111 F 10 / 100 / 1000 ميجابايت / الثانية ، تحديد تلقائي ، النصف / القدرة القصوى المزدوجة	شبكة محلية LAN
ALC898 7.1 قنوات عالية الدقة، Biostar Hi-Fi	الترميز الصوتي
منفذ x 4 نقل متسلسل عام USB 3.0 (2 في المداخل والمخرج الخلفية و 2 من خلال الموزع الداخلي) منفذ x 10 نقل متسلسل عام USB 2.0 (4 في المداخل والمخرج الخلفية و 6 من خلال الموزع الداخلي)	ناقل متسلسل عام USB
1 x فتحة منفذ الملحقات الإضافية PCI 3 x فتحة منفذ الملحقات الإضافية PCIe 2.0 x 1 1 x فتحة منفذ الملحقات الإضافية PCIe 2.0 x 16 (x4) 2 x فتحة منفذ الملحقات الإضافية PCIe 2.0 x 16 (x8, x16) قاعدة ايه إم دي AMD كروس فير (AMD CrossFire™) (x8, x8)	فتحات التوسع
1 x 2 PS/2 لوحة المفاتيح للكمبيوتر / الفأرة فتحة توصيل عدد 1 x HDMI وسيط متعدد العلي الوضوح فتحة توصيل عدد 1 x الشاشة فتحة توصيل عدد 1 x منظومة العرض المرني VGA فتحة توصيل عدد 1 x ولجة برئية رقمية DVI فتحة توصيل عدد 1 x ساتا eSATA فتحة لتوصيل عدد 1 x الشبكة المحلية LAN فتحة توصيل عدد 4 x نقل متسلسل عام USB 2.0 فتحة توصيل عدد 2 x نقل متسلسل عام USB 3.0 فتحة توصيل عدد 6 x جك الصوت	المداخل والمخارج الخلفية

المواصفات	
<p>وصلة 7 x SATA 6 جيجابايت / الثانية موزع 3 x نقل متسلسل عام USB 2.0 (كل موزع يتحمل قحتين نقل متسلسل عام USB 2.0) موزع 1 x نقل متسلسل عام USB 3.0 (كل موزع يتحمل قحتين نقل متسلسل عام USB 3.0) وصلة للطقة 1 x 8 ديبيس وصلة للطقة 1 x 24 ديوس وصلة 1 x مروحة تبريد وحدة المعالجة المركزية وصلة 2 x مراوح تبريد المنظومة موزع 1 x اللوحة الأممية موزع 1 x الصوت الأممي موزع 1 x سيموس مباشر موزع 1 x مستهلك IR موزع 1 x قحة تنسلسلية وصلة 1 x خارجية S/PDIF سوني فيليس الواجهة الرقمية</p>	المدخل والمخارج الداخلية
عامل شكل مدد التكنولوجيا المتقدمة ATX 305 مم x 244 مم	عامل الشكل
ويندوز إكس بي windows xp / ويندوز فيستا / ويندوز 7 / ويندوز 8 بيوستار BIOSTAR تحتفظ بحق إضافة أو إزالة الدعم لأي نظام تشغيل مع أو بدون أنظار.	أنظمة التشغيل المدعومة

FRENCH

Spécifications	
Support Unité Centrale	Interface de connexion FM2 pour série A AMD/processeur série E2 Enveloppe thermique Unité Centrale maximum : 100Watt * Veuillez vous reporter à www.biostar.com.tw pour la liste des supports modèles d'Unité Centrale.
Jeu de puces	AMD A85 FCH
Mémoire	Supporte mémoire DDR3 double canal 800/ 1066/ 1333/ 1600/ 1866/ 2133(OC)/ 2400(OC) Banc de mémoire 4 x DDR3 DIMM, Supporte max. jusqu'à une mémoire de 64 GB Chaque module DIMM supporte module DDR3 non-ECC 512MB/ 1/ 2/ 4/ 8/ 16 GB * Veuillez vous reporter à www.biostar.com.tw pour la liste des soutien de la mémoire.
Stockage	AMD A85 FCH Connecteur 7 x SATA 6Gb/s Supporte système RAID 0,1,10,5 & AHCI
Réseau local	Realtek RTL 8111F 10/ 100/ 1000 Mb/s auto négociation, capacité bidirectionnelle à l'alternat / bidirectionnelle simultanée
Codec audio	ALC898 Canaux 7.1, écoute audio de haute définition, Biostar Hi-Fi
USB	Port 4x USB 3.0 (2 sur les I/O arrières et 2 en interne) Port 10x USB 2.0 (4 sur les I/O arrières et 6 en interne)
Connecteur d'extension	1x Fente PCI 3x PCIe 2.0 x1 Fente 1x PCIe 2.0 x16 Fente (x4) 2x PCIe 2.0 x16 Fente (x16, x8), supports AMD CrossFireX™ (x8,x8)
I/O arrières	1x PS/2 Clavier/ Souris 1x Port HDMI 1x Port Écran 1x Port VGA 1x Port DVI 1x Port eSATA 1x port LAN 4x Port USB 2.0 2x Port USB 3.0 6x entrées audio

Spécifications	
I/O en interne	7x Connecteur SATA 6.0Gb/s 3x embases USB 2.0 (chaque embase supporte 2 Ports USB 2.0) 1x embase USB 3.0 (chaque embase supporte 2 Ports USB 3.0) 1x 8-Broche de carte 1x 24-Broche de carte 1x Connecteur ventilateur unité centrale 2x Connecteur ventilateur système 1x Fiche panneau avant 1x Fiche audio avant 1x Fiche mémoire CMOS vide 1x Fiche Registre d'état Consommateur 1x Embase port série 1x Connecteur sortie S/PDIF
Facteur d'encombrement	Facteur d'encombrement ATX, 305mm x 244 mm
Support SE	Windows XP / Vista / 7/ 8 Biostar se réserve le droit d'ajouter ou d'enlever le support pour toute SE avec ou sans préavis.

GERMAN

Spezifikationen	
CPU-Unterstützung	Anschluss-FM2 für AMD A-Serie/ E2-Serie-Prozessor Maximale CPU TDP (Thermal Design Power): 100 Watt * Bitte konsultieren Sie www.biostar.com.tw für CPU-Unterstützungsliste
Chipset	AMD A85 FCH
Festplattenspeicher	Unterstützt zweikanaliges DDR3 800/ 1066/ 1333/ 1600/ 1866/ 2133(OC)/ 2400(OC) 4 x DDR3 DIMM-SpeicherSlot, Max. Unterstützung bis zu 64 GB-Speicher Jedes DIMM unterstützt nicht-ECC 512MB/ 1/ 2/ 4/ 8/ 16 GB DDR3-Module * Bitte konsultieren Sie www.biostar.com.tw für Speicherunterstützung Liste.
Arbeitsspeicher	AMD A85 FCH: 7x SATA 6Gb-Verbindung Unterstützt RAID 0,1,10,5 & AHCI
LAN	Realtek RTL 8111F 10/ 100/ 1000 Mb Auto-Negotiation, Halb- / Voll-Duplex-fähig
Audio-Codec	ALC898 7.1 Kanäle, HD-Audio, Biostar Hi-Fi
USB	4x USB 3.0-Port (2 hintere I/Os und 2 via interne Header) 10x USB 2.0-Port (4 hintere I/Os und 6 via interne Header)
Erweiterungsanschlüsse	1x PCI-Slot 3x PCIe 2.0 x1-Slot 1x PCIe 2.0 x16-Slot (x4) 2x PCIe 2.0 x16-Slot (x16, x8), unterstützt AMD CrossFireX™ (x8,x8)
Hintere I/Os	1x PS/2-Keybaord/ Maus 1x HDMI-Port 1x Display-Port 1x VGA-Port 1x DVI-Port 1x eSATA-Port 1x LAN-Port 4x USB 2.0-Port 2x USB 3.0-Port 6x Audio Jack

Spezifikationen	
Interne I/Os	7x SATA 6.0Gb/s-Verbindung 3x USB 2.0-Header (jeder Header unterstützt 2 USB 2.0-Ports) 1x USB 3.0-Header (jeder Header unterstützt 2 USB 3.0-Ports) 1x 8-Pin-Stromverbindung 1x 24-Pin-Stromverbindung 1x CPU-Ventilatorverbindung 2x System-Ventilatorverbindung 1x Header für Frontpanel 1x Header für Frontaudio 1x Header für klares CMOS 1x Consumer IR-Header 1x Serieller Port-Header 1x S/PDIF-Auswurfsverbindung
Formfaktor	ATX Formfaktor, 305mm x 244 mm
OS-Unterstützung	Windows XP / Vista / 7/ 8 Biostar reserves the right to add or remove support for any OS with or without notice.

ITALIAN

Specificazioni	
Supporto processore	Slot FM2 per processore AMD serie-A / serie – E2 Alimentazione di Proiezione Termico (TDP – Thermal Design Power): 100Watt * Si prega di consultare www.biostar.com.tw per la lista di supporto del processore.
Tipo scheda	AMD A85 FCH
Memoria	Supporta DDR3 800/ 1066/ 1333/ 1600/ 1866/ 2133(OC)/ 2400(OC) Doppio Canale 4 x DDR3 DIMM Slot di Memoria Supporta fino a 64 GB Memoria Ogni DIMM supporta non-ECC 512MB/ 1/ 2/ 4/ 8/ 16 GB DDR3 moduli * Si prega di consultare www.biostar.com.tw per la lista di supporto del memoria.
Memorizzazione	AMD A85 FCH: Connettore 7x SATA 6Gb/s Supporta RAID 0,1,10,5 & AHCI
Catena	Realtek RTL 8111F 10/ 100/ 1000 Mb auto negoziazione, capacita di duplex Meta / Completo
Codec Audio	ALC898 Canali Audio di Alta Definizione 7.1, Biostar Hi-Fi
USB	Slot 4x USB 3.0 (2 nei ingressi/ uscite posteriore e 2 da distributori interni) Slot 10x USB 2.0 (4 nei ingressi/ uscite posteriore e 6 da distributori interni)
Slot di espansione	Slot 1x PCI Slot 3x PCIe 2.0 x1 Slot 1x PCIe 2.0 x16 (x4) Slot 2x PCIe 2.0 x16 (x16, x8), supporta AMD CrossFireX™ (x8, x8)
Ingressi/ Uscite Posteriore	Tastiera/ Mouse 1x PS/2 Slot 1x HDMI Slot 1x Display Port Slot 1x VGA Slot 1x DVI Slot 1x eSATA Slot 1x LAN Slot 4x USB 2.0 Slot 2x USB 3.0 Jack audio 6x

Specificazioni	
Ingressi/ Uscite Interni	<p>Connettore 7x SATA 6.0Gb/s</p> <p>Distributore 3x USB 2.0 (ogni distributore supporta 2 slot USB 2.0)</p> <p>Distributore 1x USB 3.0 (ogni distributore supporta 2 slot USB 3.0)</p> <p>Connettore con 8 pin x1</p> <p>Connettore con 24 pin x1</p> <p>Connettore Ventilatore processore x1</p> <p>Connettore Ventilatore Sistema x2</p> <p>Distributore Pannello Frontale x1</p> <p>Distributore Audio Frontale x1</p> <p>Distributore CMOS Diretto x1</p> <p>Distributore Consumabile IR x1</p> <p>Distributore Slot Serie x1</p> <p>Connettore esterno S/PDIF x1</p>
Fattore di Forma	Fattore di Forma ATX, 305mm x 244 mm
Supporto SO	<p>Windows XP / Vista / 7/ 8</p> <p>BioStar si riserva il diritto di aggiungere o ritirare il supporto per qualsiasi SO con o senza preavviso.</p>

JAPANESE

仕様	
CPU サポート	AMD A-シリーズ/ E2-シリーズ プロセッサの Socket FM2 最大 CPU TDP (Thermal Design Power 最大放熱量) :100 W *CPU サポート リストについては、 www.biostar.com.tw を参照してください。
チップセット	AMD A85 FCH
メモリ	デュアルチャンネル DDR3 800/ 1066/ 1333/ 1600/ 1866/ 2133(OC)/ 2400(OC) をサポート 4 x DDR3 DIMM メモリ スロット、最大 64 GB メモリまでサポート 各 DIMM は、非-ECC 512MB/ 1/ 2/ 4/ 8/ 16 GB DDR3 モジュールをサポートしています *サポートされているメモリのリストについては、 www.biostar.com.tw を参照してください。
保存スペース	AMD A85 FCH: 7x SATA 6Gb/s コネクタ RAID 0,1,10,5 & AHCI のサポート
LAN	Realtek RTL 8111F 10/ 100/ 1000 Mb/s オートネゴシエーション、半/全 二重通信
オーディオ コーデック	ALC898 7.1 チャンネル、ハイ デフィニション オーディオ、Biostar Hi-Fi
USB	4x USB 3.0 ポート (後部 I/O に2つ 及び 内蔵 ヘッダー経由に2つ) 10x USB 2.0 ポート (後部 I/O に4つ 及び 内蔵ヘッダー経由に6つ)
拡張スロット	1x PCI スロット 3x PCIe 2.0 x1 スロット 1x PCIe 2.0 x16 スロット(x4) 2x PCIe 2.0 x16 スロット(x16, x8) 、AMD CrossFireX™ (x8, x8)
後部 I/O	1x PS/2 キーボード/マウス 1x HDMI ポート 1x ディスプレイ ポート 1x VGA ポート 1x DVI ポート 1x eSATA ポート 1x LAN ポート 4x USB 2.0 ポート 2x USB 3.0 ポート 6x オーディオ ジャック

仕様	
内蔵 I/O	7x SATA 6.0Gb/s コネクタ 3x USB 2.0 ヘッダー (各ヘッダーは、2つの USB 2.0 ポートをサポートしています) 1x USB 3.0 ヘッダー (各ヘッダーは、2つの USB 3.0 ポートをサポートしています) 1x 8-Pin パワー コネクタ 1x 24-Pin パワー コネクタ 1x CPU ファン コネクタ 2x システム ファン コネクタ 1x フロント パネル ヘッダー 1x フロント オーディオ ヘッダー 1x クリア CMOS ヘッダー 1x コンシューマー IR ヘッダー 1x シリアル ポート ヘッダー 1x S/PDIF アウト コネクタ
フォーム ファクタ	ATX フォーム ファクタ、305mm x 244 mm
サポート OS	Windows XP / Vista / 7 / 8 Biostar には、通知なしでサポート OS を変更する権限があります。

POLISH

Specyfikacje techniczne	
Obsługa procesora	Gniazdo procesora (Socket) FM2 dla procesorów AMD seria-A / seria – E2 Moc Wydzielanego Ciepła (TDP - Thermal Design Power): 100Watt * Proszę sprawdzić listę obsługiwanych procesorów na stronie internetowej www.biostar.com.tw
Rodzaj płyty	AMD A85 FCH
Pamięć	Obsługa pamięci DDR3 800/ 1066/ 1333/ 1600/ 1866/ 2133(OC)/ 2400(OC) Dwukanałowa 4 x DDR3 DIMM Pamięć Gniazda procesora (Slot), Maksymalna wielkość pamięci 64 GB Każdy DIMM obsługuje jeden moduł non-ECC 512MB/ 1/ 2/ 4/ 8/ 16 GB DDR3 * Proszę sprawdzić listę obsługiwanych pamięć na stronie internetowej www.biostar.com.tw
Przechowywanie	AMD A85 FCH: Złącze 8x SATA 6Gb/s Obsługa RAID 0,1,10,5 & AHCI
LAN	Układ RTL 8111F 10/ 100/ 1000 Mb auto negocjacja, pojemność duplex Połowe / Pełny
Codec Audio	ALC898 Kanały Audio wysokiej Definicji 7.1, Biostar Hi-Fi
USB	4 x złącza USB 3.0 (2 przez tylne porty wejścia/ wyjścia oraz 2 przez wewnętrzne porty) 10 x złącza USB 2.0 (4 przez tylne porty wejścia/ wyjścia oraz 6 przez wewnętrzne porty)
Złącza rozszerzeń	złącza 1x PCI (Slot) złącze 3x PCIe 2.0 x1 (Slot) złącza 1x PCIe 2.0 x16 (Slot) (x4) złącza 2x PCIe 2.0 x16 (Slot) (x16, x8), obsługuje AMD CrossFireX™ (x8, x8)
Tylne porty wejścia/ wyjścia	Klawiatura/ Myszka 1x PS/2 Port 1x HDMI (gniazdo) Port 1x Wyświetlacza Port 1x VGA Port 1x DVI Port 1x eSATA Port 1x LAN Porty 4x USB 2.0 Porty 2x USB 3.0 Porty audio 6x

Specyfikacje techniczne	
Wewnętrzne porty wejścia/ wyjścia	<p>Złącza 7x SATA 6.0Gb/s</p> <p>Złącza 3x USB 2.0 (każde złącze obsługuje dodatkowe 2 porty USB 2.0)</p> <p>Złącze 1x USB 3.0 (każde złącze obsługuje dodatkowe 2 porty USB 3.0)</p> <p>Złącza 8 pionowe x 1</p> <p>Złącza 24 pionowe x 1</p> <p>Złącze wentylatora CPU x 1</p> <p>Złącze wentylatora obudowy x 2</p> <p>Złącze przedniego panelu x1</p> <p>Złącze audio przedniego panelu x1</p> <p>Złącze bezpośrednie CMOS x1</p> <p>Złącze konsument IR x1</p> <p>Port szeregowy x1</p> <p>Port zewnętrzny S/PDIF x1</p>
Obudowa	Obudowa ATX, 305mm x 244 mm
Obsługa OS	<p>Windows XP / Vista / 7/ 8</p> <p>Biostar zastrzega sobie prawo do dodania lub wycofania obsługi dla OS, z wypowiedzeniem lub bez wypowiedzenia.</p>

PORTUGUESE

Especificações	
Suporte Processador	Porta FM2 para processador AMD série-A / série – E2 Alimentação de Design Térmico (TDP – Thermal Design Power): 100Watt * Por favor consulte www.biostar.com.tw para obter uma lista de suporte do processador.
Tipo Placa Mãe	AMD A85 FCH
Memória	Suporta DDR3 800/ 1066/ 1333/ 1600/ 1866/ 2133(OC)/ 2400(OC) Canal Duplo 4 x DDR3 DIMM Slot de memória Suporta até 64 GB Memória Cada DIMM suporta non-ECC 512MB/ 1/ 2/ 4/ 8/ 16 GB DDR3 módulo * Por favor consulte www.biostar.com.tw para obter uma lista de suporte do memória.
Armazenamento	AMD A85 FCH: Conector 7x SATA 6Gb/s Suporta RAID 0,1,10,5 & AHCI
LAN	Realtek RTL 8111F 10/ 100/ 1000 Mb auto negociação, capacidade duplex Metade / Cheio
Codec de Audio	ALC898 Canais de Áudio de Alta Definição 7.1, Biostar Hi-Fi
USB	Porta 4x USB 3.0 (2 nas entradas/saídas traseiras e 2 pelos Dispositivos internos) Porta 10x USB 2.0 (4 nas entradas/saídas traseiras e 6 pelos Dispositivos internos)
Slots de expansão	Porta 1x PCI Porta 3x PCIe 2.0 x1 Porta 1x PCIe 2.0 x16 (x4) Porta 2x PCIe 2.0 x16 (x16, x8), suporta AMD CrossFireX™ (x8, x8)
Entradas/Saídas no painel traseiro	Teclado/ Mouse 1x PS/2 Porta 1x HDMI Porta 1x Display Porta 1x VGA Porta 1x DVI Porta 1x eSATA Porta 1x LAN Porta 4x USB 2.0 Porta 2x USB 3.0 Soquete audio 6x

Especificações	
Conectores na placa	<p>Conector 7x SATA 6.0Gb/s</p> <p>Dispositivo 3x USB 2.0 (cada Dispositivo suporta 2 portas USB 2.0)</p> <p>Dispositivo 1x USB 3.0 (cada Dispositivo suporta 2 portas USB 3.0)</p> <p>Conector de 8 pinos x1</p> <p>Conector de 24 pinos x1</p> <p>Conector de Ventoinha processador x1</p> <p>Conector de Ventoinha Sistema x1</p> <p>Dispositivo Painel Frontal x1</p> <p>Dispositivo de Audio Frontal x1</p> <p>Dispositivo CMOS Direct x1</p> <p>Dispositivo Consumível IR x1</p> <p>Dispositivo Porta Impressora x1</p> <p>Dispositivo Porta Série x1</p> <p>Conector Externo S/PDIF x1</p>
Fator de Fôrma	Fator de Fôrma ATX, 305mm x 244 mm
Suporte OS	<p>Windows XP / Vista / 7/ 8</p> <p>Biostar reserva seu direito de adicionar ou retirar o suporte para qualquer OS com ou sem notificação.</p>

RUSSIAN

Спецификации	
Поддержка центрального процессора	Сокет FM2 для процессоров AMD серии A/ серии E2 Максимальный термopakет центрального процессора (TDP): 100 ватт * Перечень поддержки центрального процессора смотрите на www.biostar.com.tw .
Набор микросхем	AMD A85 FCH
Память	Поддерживает двухканальный DDR3 800/ 1066/ 1333/ 1600/ 1866/ 2133(OC)/ 2400(OC) 4 гнезда платы памяти DDR3 DIMM, максимальная память до 64 Гб Каждый модуль DIMM поддерживает модуль не-ECC 512 Мб/ 1/ 2/ 4/ 8/ 16 Гб DDR3 * Перечень поддержки памяти смотрите на www.biostar.com.tw .
Накопитель	AMD A85 FCH: Соединитель 8x SATA 6 Гб/с Поддерживает RAID 0,1,10,5 & AHCI
Локальная сеть	Realtek RTL 8111F Автосогласование 10/ 100/ 1000 Мб/с, работает в полно/полудуплексном режиме
Аудиокодек	ALC898 Каналы 7.1, высококачественное аудио, Biostar Hi-Fi
USB	4 порта USB 3.0 (2 сзади ввода-вывода и 2 через внутренние контакты) 10 порта USB 2.0 (4 сзади ввода-вывода и 6 через внутренние контакты)
Гнезда расшир.	1x гнезда PCI 3x PCIe 2.0 x1 гнездо 1x PCIe 2.0 x16 гнездо (x4) 2x PCIe 2.0 x16 гнездо (x16, x8), поддерживает AMD CrossFireX™ (x8, x8)
Задняя плата ввода-вывода	1 клавиатура/ мышь PS/2 1 порт HDMI 1 порт дисплея 1 порт VGA 1 порт DVI 1 порта eSATA 1 порт локальной сети 4 порта USB 2.0 2 порта USB 3.0 6 гнезд для подключения наушников

Спецификации	
Внутр. Плата ввода-вывода	<p>Соединитель 7x SATA 6 Гб/с</p> <p>3 контакта USB 2.0 (каждый контакт поддерживает 2 порта USB 2.0)</p> <p>1 контакт USB 3.0 (каждый контакт поддерживает 2 порта USB 3.0)</p> <p>1 8-выводный разъем питания</p> <p>1 24-выводный разъем питания</p> <p>1 разъем вентилятора ЦП</p> <p>2 разъема вентилятора системы</p> <p>1 контакт передней панели</p> <p>1 контакт передней аудиопанели</p> <p>1 контакт микросхемы Clear CMOS</p> <p>1 инфракрасный пользовательский контакт</p> <p>1 контакт последовательного порта</p> <p>1 соединитель S/PDIF-Out</p>
Конструктив	Форм-фактор ATX, 305мм x 244 мм
Поддержка ОС	<p>Windows XP / Vista / 7/ 8</p> <p>Biostar оставляет за собой право добавлять или удалять поддержку любой ОС, с уведомлением или без.</p>

SPANISH

Especificaciones	
Compatibilidad con el procesador	Ranura FM2 para procesador AMD serie - A / serie - E2 Alimentación de Proyección Térmica (TDP - Thermal Design Power): 100Watt *Por favor consultar con www.biostar.com.tw para la lista de compatibilidad con el procesador.
Tipo de Placa	AMD A85 FCH
Memoria	Soporta DDR3 800/ 1066/ 1333/ 1600/ 1866/ 2133(OC)/ 2400(OC) Doble Canal 4x DDR3 DIMM Ranura de memoria Soporta hasta 64 GB Memoria Cada DIMM soporta un modulo non-ECC 512MB/ 1/ 2/ 4/ 8/ 16 GB DDR3 *Por favor consultar con www.biostar.com.tw para la lista de compatibilidad con el memoria.
Almacenamiento de información	AMD A85 FCH: Conector 8x SATA 6Gb/s Soporta RAID 0,1,10,5 & AHCI
LAN	Realtek RTL 8111F 10/ 100/ 1000 Mb/s auto negociación, capacidad dúplex Mitad/Completo
Códec Audio	ALC898 Canales Audio de Alta Definición 7.1, Biostar Hi-Fi
USB	Ranura 4x USB 3.0 (2 en las entrada/salidas posteriores y 2 por los distribuidores internos) Ranura 10x USB 2.0 (4 en las entrada/salidas posteriores y 6 por los distribuidores internos)
Ranuras de Extinción	Ranura 1x PCI Ranura 3x PCIe 2.0 x1 Ranura 1x PCIe 2.0 x16 (x4) Ranura 2x PCIe 2.0 x16 (x16, x8), soporta AMD CrossFireX™ (x8, x8)
Panel trasero de E/S	Teclado/ Ratón 1x PS/2 Ranura 1x HDMI Ranura 1x Pantalla Ranura 1x VGA Ranura 1x DVI Ranura 1x eSATA Ranura 1x LAN Ranura 4x USB 2.0 Ranura 2x USB 3.0 Socket audio 6x

Especificaciones	
Conectores en placa	<p>Conector 7x SATA 6Gb/s</p> <p>Distribuidor 3x USB 2.0 (cada distribuidor soporta 2 ranuras USB 2.0)</p> <p>Distribuidor 1x USB 3.0 (cada distribuidor soporta 2 ranuras USB 3.0)</p> <p>Conector con 8 patillas x1</p> <p>Conector con 24 patillas x1</p> <p>Conector Ventilador procesador x1</p> <p>Conector Ventilador Sistema x2</p> <p>Distribuidor Panel Frontal x1</p> <p>Distribuidor Audio Frontal x1</p> <p>Distribuidor CMOS Directo x1</p> <p>Distribuidor Consumible IR x1</p> <p>Distribuidor Ranura Serie x1</p> <p>Conector Externo S/PDIF x1</p>
Factor de Forma	Factor de Forma ATX, 305mm x 244 mm
Soporte OS	<p>Windows XP / Vista / 7/ 8</p> <p>BioStar reserva su derecho de añadir o retirar el soporte para cada OS con o sin notificación.</p>

2012/12/12