

# ***P4TDQ Pro***

---

## **FCC Statement and Copyright**

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation.

The vendor makes no representations or warranties with respect to the contents here of and specially disclaims any implied warranties of merchantability or fitness for any purpose. Further the vendor reserves the right to revise this publication and to make changes to the contents here of without obligation to notify any party beforehand.

Duplication of this publication, in part or in whole is not allowed without first obtaining the vendor's approval in writing.

The content of this user's is subject to be changed without notice and we will not be responsible for any mistakes found in this user's manual. All the brand and product names are trademarks of their respective companies.

## Contents

---

<b>ENGLISH</b> .....	<b>1</b>
P4TDQ Pro Features .....	1
Package contents .....	1
Layout of P4TDQ Pro.....	2
CPU Installation .....	3
DDR DIMM Modules: DDR1-2.....	4
Jumpers, Headers, Connectors & Slots .....	5
<b>ESPAÑOL</b> .....	<b>10</b>
Características del P4TDQ Pro .....	10
Contenido del Paquete.....	10
Disposición del P4TDQ Pro .....	11
Instalación de la CPU.....	12
Módulos DDR DIMM: DDR1-2.....	13
Conectores, Cabezales, Puentes y Ranuras .....	14
<b>WARPSPEEDER</b> .....	<b>19</b>
Introduction.....	19
System Requirement .....	20
Installation .....	20
Usage .....	22
<b>TROUBLE SHOOTING</b> .....	<b>30</b>
<b>SOLUCIÓN DE PROBLEMAS</b> .....	<b>31</b>

## ***Motherboard Description***

---

### **English**

#### **P4TDQ Pro Features**

- ✦ Use Intel 82845GL/ 82801DB Chipset, ITE IT8712F, LAN Chip (optional).
- ✦ Contains on board I/O facilities, which include one serial port, one VGA port, a parallel port, a PS/2 mouse port, a PS/2 key board port, audio ports, USB ports, a LAN port (optional) and a game port.
- ✦ Supports the Intel Pentium 4<sup>®</sup> (Socket 478) processor up to 306GHz.
- ✦ Supports Ultra 100/66/33, BMIDE and PIO modes.
- ✦ Supports USB2.0 High Speed Device.
- ✦ Supports up to 2 DDR 200/266/333 MHz (without ECC) devices, running at Fuzzy 533 MHz Front Side Bus frequency.
- ✦ Supports one CNR Slot (Type A only), and three 32-bit PCI Bus slots.
- ✦ Complies with FC Micro-ATX form factor specifications.
- ✦ Supports popular operating systems such as Windows 98, Windows NT, Windows 2000, Windows ME, Windows XP, LINUX and SCO UNIX.
- ✦ Intel<sup>®</sup> AC'97 2.2 compatible.
- ✦ High SN ratio meets PC 99 requirements.
- ✦ 6CH DAC, applicable for leading motherboard chipsets.
- ✦ Line-In phonejack share with rear out.
- ✦ Mic-In phonejack share with Bass & Center.
- ✦ Supports Front Audio pin head functions.


#### **Package contents**

- ✦ HDD Cable X 1, FDD Cable X 1, Fully Setup Driver CD X 1
- ✦ Flash Memory Writer for BIOS update X 1

## Motherboard Description

- ✦ USB Cable X 2 (Optional)
- ✦ Rear I/O Panel for ATX Case X 1 (Optional)


### Layout of P4TDQ Pro



## Motherboard Description



---

### CPU Installation



1. Pull the lever sideways away from the socket then raise the lever up to 90-degree angle.
2. Locate Pin A in the socket and lock for the white dot or cut edge in the CPU. Match Pin A with the white dot/cut edge then insert the CPU.
3. Press the lever down. Then Put the fan on the CPU and buckle it and put the fan's power port into the JCFAN1, then to complete the installation.

### CPU/ System Fan Headers: JCFAN1/ JSFAN1



## Motherboard Description

---

### DDR DIMM Modules: DDR1-2

DRAM Access Time: 2.5V Unbuffered DDR 200/266/Fuzzy 333 MHz  
Type required.  
DRAM Type: 64MB/ 128MB/ 256MB/ 512MB/ 1GB DIMM Module (184 pin)

DIMM Socket Location	DDR Module	Total Memory Size (MB)
DDR 1	64MB/128MB/256MB/512MB/1GB *1	Max is 2GB
DDR 2	64MB/128MB/256MB/512MB/1GB *1	


\* The list shown above for DRAM configuration is only for reference.

### How to install a DIMM Module

1. The DIMM socket has a "Plastic Safety Tab", and the DIMM memory module has an "Asymmetrical notch", so the DIMM memory module can only fit into the slot in one direction.

2. Push the tabs out. Insert the DIMM memory modules into the socket at a 90-degree angle, then push down vertically so that it will fit into the place.

3. The Mounting Holes and plastic tabs should fit over the edge and hold the DIMM memory modules in place.



## Motherboard Description

---

### Jumpers, Headers, Connectors & Slots

#### Hard Disk Connectors: IDE1/ IDE2

The motherboard has a 32-bit Enhanced PCI IDE Controller that provides PIO Mode 0~4, Bus Master, and Ultra DMA / 33/ 66/ 100 functionality. It has two HDD connectors IDE1 (primary) and IDE2 (secondary).

The IDE connectors can connect a master and a slave drive, so you can connect up to four hard disk drives. The first hard drive should always be connected to IDE1.

#### Floppy Disk Connector: FDD1

The motherboard provides a standard floppy disk connector that supports 360K, 720K, 1.2M, 1.44M and 2.88M floppy disk types. This connector supports the provided floppy drive ribbon cables.


#### Communication Network Riser Slot: CNR1

The CNR specification is an open Industry Standard Architecture, and it defines a hardware scalable riser card interface, which supports audio, network and modem only.

#### Peripheral Component Interconnect Slots: PCI-3

This motherboard is equipped with 3 standard PCI slots. PCI stands for Peripheral Component Interconnect, and it is a bus standard for expansion cards, which has supplanted the older ISA bus standard in most ports. This PCI slot is designated as 32 bits.


#### Power Connectors: JATXPWR1/ JATXPWR2




## Motherboard Description

---


### Wake On LAN Header: WOL1




### Front USB Header: JUSB1/ JUSB2



### 5V/5VSB Selection for USB: JUSBV1/JUSBV3/ JUSBV4



### Digital Audio Connector: JSPDIF\_OUT







## **Motherboard Description**

---

### **Front Panel Connector: JPANEL1**



### **Audio Subsystem: JAUDIO1/ JCDIN1**



## Motherboard Description

---



Pin	Assignment	Pin	Assignment
1	Mic In	2	Ground
3	Mic Power	4	Audio Power
5	RT Line Out	6	RT Line Out
7	Reserved	8	Key
9	LFT Line Out	10	LFT Line Out
11	RT Line In	12	RT Line In
13	LFT Line In	14	LFT Line In

Pin 5, 9, 11, 13 are routed to Front Panel Audio Out.  
 Pin 6, 10, 12, 14 are routed from Front Panel Audio Out.


### Front Panel Audio Connector/ Jumper Block

Jumper Setting	Configuration
<p>Pin 5 and 6                      Pin 9 and 10                      Pin 11 and 12                      Pin 13 and 14</p>	Audio line out signals are routed to the back panel audio line out connector.
<p>No jumpers installed</p>	Audio line out and mic in signals are available for front panel audio connectors.


## Motherboard Description

---

### Clear CMOS Jumper: JCMOS1



### Back Panel Connectors



## ***Motherboard Description***

---

### **Español**

#### **Características del P4TDQ Pro**

- ✦ Usa Chipset Intel 82845GL/ 82801DB, ITE IT8712F, LAN Chip (opcional).
- ✦ Contiene facilidades I/O integradas en la placa madre en el que incluye un puerto en serie paralelo, un puerto VGA, un puerto paralelo, un puerto para ratón PS/2, un puerto para teclado PS/2, puertos de audio, puertos USB, puerto LAN (opcional) y un puerto para juegos.
- ✦ Soporta procesador Intel Pentium 4® (Socket 478) hasta 3.06GHz.
- ✦ Soporta Ultra 100/66/33, BMIDE y modo FIO.
- ✦ Soporta Dispositivo de Alta Velocidad USB2.0.
- ✦ Soporta hasta 2 dispositivos DDR 200/266/Fuzzy333 MHz (no incluye ECC), corriendo a Fuzzy 533 MHz frecuencia Front Side Bus.
- ✦ Soporta una ranura CNR (solamente de tipo A), y tres ranuras PCI Bus de 32-bit.
- ✦ Compatible con la forma de PC Micro-ATX
- ✦ Soporta sistemas operativos populares tales como Windows 98, Windows NT, Windows 2000, Windows ME, Windows XP, LINUX y SCO UNIX.
- ✦ Intel® AC'97 2.2 compatible.
- ✦ Requisitos High S/N ratio para PC 99.
- ✦ 6CH DAC, aplicable para chipsets de la placa madre.
- ✦ Entrada de Línea compartido con el rear out.
- ✦ Entrada del MIC compartido con Bass & Center.
- ✦ Soporta funciones de contactos del cabezal de audio frontal.


#### **Contenido del Paquete**

- ✦ Cable HDD X 1, Cable FDD X 1, Completo Setup Driver CD X 1
- ✦ Memoria Flash Writer para actualización del BIOS X 1

## Motherboard Description

- ❖ Cable USB X 2 (Opcional)
- ❖ Panel trasero I/O para caja ATX X 1 (Opcional)


### Disposición del P4TDQ Pro



## Motherboard Description



---

### Instalación de la CPU



1. Tire de la palanca del lado del zócalo, luego levante la palanca hasta un ángulo de 90 grados.
2. Sitúe el contacto A del zócalo y busque el punto blanco o corte el borde en la CPU. Empareje el contacto A con el punto blanco/corte del borde, luego inserte la CPU.
3. Presione la palanca para abajo. Ponga el ventilador en la CPU y abróchelo. Luego ponga el puerto de corriente del ventilador en el JCFAN1. Y ya habrá completado su instalación.

### CPU/ Cabezales del Sistemas de Ventilación: JCFAN1/ JSFAN1



## Motherboard Description

### Módulos DDR DIMM: DDR1-2

DRAM Tiempo de Acceso: 2.5V Unbuffered DDR 200/266/Fuzzy 333 MHz Tipo requerido.  
DRAM Tipo: 64MB/ 128MB/ 256MB/ 512MB/ 1GB Módulos DIMM (184 Contactos)

Localización del Zócalo DIMM	Módulo DDR	Total del Tamaño de Memoria (MB)
DDR 1	64MB/128MB/256MB/512MB/1GB *1	Máxima es 2GB
DDR 2	64MB/128MB/256MB/512MB/1GB *1	


\* La lista de arriba para la configuración DRAM es solamente para referencia.

### Cómo instalar un módulo DIMM

1. El zócalo DIMM tiene una lengüeta plástica de seguridad y el módulo de memoria DIMM tiene una muesca asimétrica, así el módulo de memoria DIMM puede caber solamente en la ranura de una sola dirección.

2. Tire la lengüeta hacia afuera. Inserte los módulos de memoria DIMM en el zócalo a los 90 grados, luego empuje hacia abajo verticalmente de modo que encaje en el lugar.

3. Los agujeros de montaje y las lengüetas plásticas deben caber por sobre el borde y sostenga los módulos de memoria DIMM en el lugar.



## Motherboard Description

---

### Conectores, Cabezales, Puentes y Ranuras

#### Conectores del Disco Duro: IDE1/ IDE2

La placa madre tiene un controlador de 32-bit PCI IDE que proporciona Modo PIO 0-4, Bus Master, y funcionalidad Ultra DMA / 33/ 66/ 100. Tiene dos conectores HDD IDE1 (primario) y IDE2 (secundario).

El conector IDE puede conectar a un master y un drive esclavo, así puede conectar hasta cuatro discos rígidos. El primer disco duro debe estar siempre conectado al IDE1.

#### Conector para el Disquete: FDD1

La placa madre proporciona un conector estándar del disquete (FDC) que soporta 360K, 720K, 1.2M, 1.44M y 2.88M tipos de disquete. Este conector utiliza los cables de cinta proporcionados por el disquete.

#### Ranura de Canalización de la Red de Comunicación:

##### CNR1


La especificación CNR es una abierta Industria Estándar de Arquitectura, y define una tarjeta hardware escalable de interfaz en el que soporta audio, red y módem.

#### Ranura de Interconexión del Componente Periférico:

##### PCI-3

Esta placa madre está equipada con 3 ranuras PCI. PCI es la sigla para Interconexión del Componente Periférico, y es un estándar bus para la tarjeta de expansión en el que reemplaza, en su mayoría de las partes, al antiguo estándar ISA bus. Las ranuras de PCI están diseñadas con 32 bits

#### Conectores de Encendido: JATXPWR1/ JATXPWR2







## **Motherboard Description**

---

### **Cabezal Wake On LAN: WOL1**




### **Cabezal Frontal USB: JUSB1/ JUSB2**



### **5V/5VSB Selección para USB: JUSBV1/ JUSBV3/ JUSBV4**




### **Conector Digital de Audio: JSPDIF\_OUT**




## Motherboard Description

---

### Conector del Panel Frontal: JPANEL1



### Subsistema de Audio: JAUDIO1/ JCDIN1



## Motherboard Description



Contactos	Asignacion	Contactos	Asignacion
1	Entrada del MIC	2	Tierra
3	Corriente del MIC	4	Corriente de Audio
5	RT Salida de Linea	6	RT Salida de Linea
7	Reservado	8	Key
9	LFT Salida de Linea	10	LFT Salida de Linea
11	RT Entrada de Linea	12	RT Entrada de Linea
13	LFT Entrada de Linea	14	LFT Entrada de Linea

Contactos 5, 9, 11, 13 son encaminados a la Salida de Audio del Panel Frontal.

Contactos 6, 10, 12, 14 son encaminados desde la Salida de Audio del Panel Frontal.

### Conector del Panel Frontal de Audio/ Jumper Block

<i>Jumper Setting</i>	<i>Configuracion</i>
<p>           1 2            3 4            5 6    Contacto 5 &amp; 6            7 8    Contacto 9 &amp; 10            9 10    Contacto 11 &amp; 12            11 12    Contacto 13 &amp; 14            13 14         </p>	<p>La señal de salida de línea del Audio encamina al conector de la salida de línea del Audio ubicado en el panel trasero.</p>
<p>           1 2            3 4            5 6            7 8            9 10            11 12            13 14    No jumpers installed         </p>	<p>La señal de salida de línea del Audio y la señal del entrada del mic están disponibles desde el conector de Audio del panel frontal.</p>

## Motherboard Description

---


### Puente de Borrar CMOS: JCMOS1



Contacto 1-2 on ==> Operación Normal (default)  
Contacto 2-3 on ==> Borrar Datos CMOS

JCMOS1

### Conectores del Panel Trasero



## ***Motherboard Description***

---

### **WarpSpeeder**



### **Introduction**

[ WarpSpeeder™ ], a new powerful control utility, features three user-friendly functions including Overclock Manager, Overvoltage Manager, and Hardware Monitor.

With the Overclock Manager, users can easily adjust the frequency they prefer or they can get the best CPU performance with just one click. The Overvoltage Manager, on the other hand, helps to power up CPU core voltage and Memory voltage. The cool Hardware Monitor smartly indicates the temperatures, voltage and CPU fan speed as well as the chipset information. Also, in the About panel, you can get detail descriptions about BIOS model and chipsets. In addition, the frequency status of CPU, memory, AGP and PCI along with the CPU speed are synchronically shown on our main panel.

Moreover, to protect users' computer systems if the setting is not appropriate when testing and results in system fail or hang, [ WarpSpeeder™ ] technology assures the system stability by automatically rebooting the computer and then restart to a speed that is either the original system speed or a suitable one.

## ***Motherboard Description***

---

### **System Requirement**

OS Support: Windows 98 SE, Windows Me, Windows 2000, Windows XP

DirectX: DirectX 8.1 or above. (The Windows XP operating system includes DirectX 8.1. If you use Windows XP, you do not need to install DirectX 8.1.)

### **Installation**

1. Execute the setup execution file, and then the following dialog will pop up. Please click "Next" button and follow the default procedure to install.



## ***Motherboard Description***

---

2. When you see the following dialog in setup procedure, it means setup is completed. If the “Launch the WarpSpeeder Tray Utility” checkbox is checked, the Tray Icon utility and [ WarpSpeeder™ ] utility will be automatically and immediately launched after you click “Finish” button.



## Motherboard Description

---


### Usage

*The following figures are just only for reference, the screen printed in this user manual will change according to your motherboard on hand.*


[ WarpSpeeder™ ] includes 1 tray icon and 5 panels:

1. Tray Icon:

Whenever the Tray Icon utility is launched, it will display a little tray icon on the right side of Windows Taskbar.



This utility is responsible for conveniently invoking [ WarpSpeeder™ ] Utility. You can use the mouse by clicking the left button in order to invoke [ WarpSpeeder™ ] directly from the little tray icon or you can right-click the little tray icon to pop up a popup menu as following figure. The "Launch Utility" item in the popup menu has the same function as mouse left-click on tray icon and "Exit" item will close Tray Icon utility if selected.





## ***Motherboard Description***

---

### 2. Main Panel

If you click the tray icon, [ WarpSpeeder™ ] utility will be invoked. Please refer to the following figure; the utility's first window you will see is Main Panel.


Main Panel contains features as follows:

- a. Display the CPU Speed, CPU external clock, Memory clock, AGP clock, and PCI clock information.
- b. Contains About, Voltage, Overclock, and Hardware Monitor Buttons for invoking respective panels.
- c. With a user-friendly Status Animation, it can represent 3 overclock percentage stages:

Man walking => overclock percentage from 100% ~ 110 %

Panther running => overclock percentage from 110% ~ 120%

Car racing => overclock percentage from 120% ~ above



## Motherboard Description

---

### 3. Voltage Panel

Click the Voltage button in Main Panel, the button will be highlighted and the Voltage Panel will slide out to up as the following figure.

In this panel, you can decide to increase CPU core voltage and Memory voltage or not. The default setting is "No". If you want to get the best performance of overclocking, we recommend you click the option "Yes".



## Motherboard Description

---

### 4. Overclock Panel


Click the Overclock button in Main Panel, the button will be highlighted and the Overclock Panel will slide out to left as the following figure.

Overclock Panel contains the these features:

- a. “-3MHz button”, “-1MHz button”, “+1MHz button”, and “+3MHz button”: provide user the ability to do real-time overcløck adjustment.

*Warning: Manually overclock is potentially dangerous, especially when the overlocking percentage is over 110 %. We strongly recommend you verify every speed you overclock by click the Verify button. Or, you can just click Auto overclock button and let [ WarpSpeeder™ ] automatically gets the best result for you.*

- b. “Recovery Dialog button”: Pop up the following dialog. Let user select a restoring way if system need to do a fail-safe reboot.



- c. “Auto-overclock button”: User can click this button and [ WarpSpeeder™ ] will set the best and stable performance and frequency automatically. [ WarpSpeeder™ ] utility will execute a series of testing until system fail. Then system will do fail-safe reboot by using Watchdog function. After reboot, the [ WarpSpeeder™ ] utility will restore to the hardware default setting or load the verified best and stable frequency according to the Recovery Dialog's setting.

## Motherboard Description

---

- d. "Verify button": User can click this button and [ WarpSpeeder™ ] will proceed a testing for current frequency. If the testing is ok, then the current frequency will be saved into system registry. If the testing fail, system will do a fail-safe rebooting. After reboot, the [ WarpSpeeder™ ] utility will restore to the hardware default setting or load the verified best and stable frequency according to the Recovery Dialog's setting.

*Note: Because the testing programs, invoked in Auto-overclock and Verify, include DirectDraw, Direct3D and DirectShow tests, the DirectX 8.1 or newer runtime library is required. And please make sure your display card's color depth is High color (16 bit) or True color (24/32 bit) that is required for Direct3D rendering.*



## Motherboard Description

---

### 5. Hardware Monitor Panel

Click the Hardware Monitor button in Main Panel, the button will be highlighted and the Hardware Monitor panel will slide out to left as the following figure.

In this panel, you can get the real-time status information of your system. The information will be refreshed every 1 second.



### 6. About Panel

Click the About button in Main Panel, the button will be highlighted and the About Panel will slide out to up as the following figure.

In this panel, you can get model name and detail information in hints of all the chipset that are related to overclocking. You can also get the motherboard's BIOS model and the Version number of [ WarpSpeeder™ ] utility.

## Motherboard Description

---



## **Motherboard Description**

---

*Note: Because the overclock, overvoltage, and hardware monitor features are controlled by several separate chipset, [ WarpSpeeder™ ] divide these features to separate panels. If one chipset is not on board, the correlative button in Main panel will be disabled, but will not interfere other panels' fundions. This property can make [ WarpSpeeder™ ] utility more robust.*

---

## Trouble Shooting

PROBABLE	SOLUTION
No power to the system at all Power light don't illuminate, fan inside power supply does not turn on. Indicator light on keyboard does not turn on.	<ul style="list-style-type: none"> <li>* Make sure power cable is securely plugged in</li> <li>* Replace cable</li> <li>* Contact technical support</li> </ul>

PROBABLE	SOLUTION
System inoperative. Keyboard lights are on, power indicator lights are lit, hard drive is spinning.	<ul style="list-style-type: none"> <li>* Using even pressure on both ends of the DIMM, press down firmly until the module snaps into place.</li> </ul>

PROBABLE	SOLUTION
System does not boot from hard disk drive, can be booted from CD-ROM drive.	<ul style="list-style-type: none"> <li>* Check cable running from disk to disk controller board. Make sure both ends are securely plugged in; check the drive type in the standard CMOS setup.</li> <li>* Backing up the hard drive is extremely important. All hard disks are capable of breaking down at any time.</li> </ul>

PROBABLE	SOLUTION
System only boots from CD-ROM Hard disk can be read and applications can be used but booting from hard disk is impossible.	<ul style="list-style-type: none"> <li>* Backup data and applications files. Reformat the hard drive. Re-install applications and data using backup disks.</li> </ul>

PROBABLE	SOLUTION
Screen message says "Invalid Configuration" or "CMOS Failure."	<ul style="list-style-type: none"> <li>* Review system's equipment . Make sure correct information is in setup.</li> </ul>

PROBABLE	SOLUTION
Cannot boot system after installing second hard drive.	<ul style="list-style-type: none"> <li>* Set master/slave jumpers correctly.</li> <li>* Run SETUP program and select correct drive types. Call drive manufacturer for compatibility with other drives.</li> </ul>



## Solución de Problemas

CAUSA PROBABLE	SOLUCIÓN
No hay corriente en el sistema. La luz de corriente no ilumina, ventilador dentro de la fuente de alimentación apagada. Indicador de luz del teclado apagado.	<ul style="list-style-type: none"> <li>* Asegúrese que el cable de transmisión esté seguramente enchufado.</li> <li>* Reemplace el cable.</li> <li>* Contacte ayuda técnica.</li> </ul>
Sistema inoperativo. Luz del teclado encendido, luz de indicador de corriente iluminado, disco rígido está girando.	<ul style="list-style-type: none"> <li>* Presione los dos extremos del DIMM, presione para abajo firmemente hasta que el módulo encaje en el lugar.</li> </ul>
Sistema no arranca desde el disco rígido, puede ser arrancado desde el CD-ROM drive.	<ul style="list-style-type: none"> <li>* Controle el cable de ejecución desde el disco hasta el disco del controlador. Asegúrese de que ambos lados estén enchufados con seguridad; controle el tipo de disco en la configuración estándar CMOS.</li> <li>* Copiando el disco rígido es extremadamente importante. Todos los discos rígidos son capaces de dañarse en cualquier momento.</li> </ul>
Sistema solamente arranca desde el CD-ROM. Disco rígido puede leer y aplicaciones pueden ser usados pero el arranque desde el disco rígido es imposible.	<ul style="list-style-type: none"> <li>* Copie datos y documentos de aplicación. Vuelva a formatear el disco rígido. Vuelva a instalar las aplicaciones y datos usando el disco de copiado.</li> </ul>
Mensaje de pantalla "Invalid Configuration" o "CMOS Failure"	<ul style="list-style-type: none"> <li>* Revise el equipo del sistema. Asegúrese de que la información configurada sea correcta.</li> </ul>
No puede arrancar después de instalar el segundo disco rígido.	<ul style="list-style-type: none"> <li>* Fije correctamente el puente master/esdavo.</li> <li>* Ejecute el programa SETUP y seleccione el tipo de disco correcto. Llame a una manufacturación del disco para compatibilidad con otros discos.</li> </ul>



11/12/2002



# ***P4TDQ Pro BIOS Setup***

---

<b>BIOS Setup</b> .....	<b>1</b>
1 Main Menu.....	3
2 Standard CMOS Features .....	6
3 Advanced BIOS Features.....	9
4 Advanced Chipset Features.....	12
5 Integrated Peripherals .....	15
6 Power Management Setup .....	19
7 PnP/PCI Configurations .....	24
8 PC Health Status .....	26
9 Frequency Control .....	28

# ***P4TDQ Pro BIOS Setup***

---

## **BIOS Setup**

### **Introduction**

This manual discussed Award™ Setup program built into the ROM BIOS. The Setup program allows users to modify the basic system configuration. This special information is then stored in battery-backed RAM so that it retains the Setup information when the power is turned off.

The Award BIOS™ installed in your computer system's ROM (Read Only Memory) is a custom version of an industry standard BIOS. This means that it supports Intel Pentium® 4 processor input/output system. The BIOS provides critical low-level support for standard devices such as disk drives and serial and parallel ports.

Adding important has customized the Award BIOS™, but nonstandard, features such as virus and password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

The rest of this manual is intended to guide you through the process of configuring your system using Setup.

### **Plug and Play Support**

These AWARD BIOS supports the Plug and Play Version 1.0A specification. ESCD (Extended System Configuration Data) write is supported.

### **EPA Green PC Support**

This AWARD BIOS supports Version 1.03 of the EPA Green PC specification.

### **APM Support**

These AWARD BIOS supports Version 1.1&1.2 of the Advanced Power Management (APM) specification. Power management features are implemented via the System Management Interrupt (SMI). Sleep and Suspend power management modes are supported. Power to the hard disk drives and video monitors can be managed by this AWARD BIOS.

# **P4TDQ Pro BIOS Setup**

---

## **PCI Bus Support**

This AWARD BIOS also supports Version 2.1 of the Intel PCI (Peripheral Component Interconnect) local bus specification.

## **DRAM Support**

DDR SDRAM (Double Data Rate Synchronous DRAM) are supported.

## **Supported CPUs**

This AWARD BIOS supports the Intel Pentium<sup>®</sup> 4 CPU.

## **Using Setup**

In general, you use the arrow keys to highlight items, press <Enter> to select, use the <PgUp> and <PgDn> keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program by using the keyboard.

<b>Keystroke</b>	<b>Function</b>
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left (menu bar)
Right arrow	Move to the item on the right (menu bar)
Move Enter	Move to the item you desired
PgUp key	Increase the numeric value or make changes
PgDn key	Decrease the numeric value or make changes
+ Key	Increase the numeric value or make changes
- Key	Decrease the numeric value or make changes
Esc key	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu – Exit Current page and return to Main Menu
F1 key	General help on Setup navigation keys
F5 key	Load previous values from CMOS
F6 key	Load the fail-safe defaults from BIOS default table
F7 key	Load the optimized defaults
F10 key	Save all the CMOS changes and exit

# P4TDQ Pro BIOS Setup

---


## 1 Main Menu

Once you enter Award BIOS™ CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

**!! WARNING !!**

The information about BIOS defaults on manual (**Figure 1,2,3,4,5,6,7,8,9**) is just for reference, please refer to the BIOS installed on board, for update information.

### ■ Figure 1. Main Menu



### Standard CMOS Features

This submenu contains industry standard configurable options.

### Advanced BIOS Features

This submenu allows you to configure enhanced features of the BIOS.

# P4TDQ Pro BIOS Setup

---

## Advanced Chipset Features

This submenu allows you to configure special chipset features.

## Integrated Peripherals

This submenu allows you to configure certain IDE hard drive options and Programmed Input/ Output features.

## Power Management Setup

This submenu allows you to configure the power management features.

## PnP/PCI Configurations

This submenu allows you to configure certain “Plug and Play” and PCI options.

## PC Health Status


This submenu allows you to monitor the hardware of your system.

## Frequency Control

This submenu allows you to change CPU Vcore Voltage and CPU/PCI clock. **(However, this function is strongly recommended not to use. Not properly change the voltage and clock may cause CPU or M/B damage!)**

## Load Optimized Defaults

This selection allows you to reload the BIOS when the system is having problems particularly with the boot sequence. These configurations are factory settings optimized for this system. A confirmation message will be displayed before defaults are set.



```
Load Optimized Defaults (Y/N)? N
```

## Set Supervisor Password

Setting the supervisor password will prohibit everyone except the supervisor from making changes using the CMOS Setup Utility. You will be prompted with to enter a password.



```
Enter Password:
```

# P4TDQ Pro BIOS Setup

---

## Set User Password

If the Supervisor Password is not set, then the User Password will function in the same way as the Supervisor Password. If the Supervisor Password is set and the User Password is set, the "User" will only be able to view configurations but will not be able to change them.

```
Enter Password:
```

## Save & Exit Setup

Save all configuration changes to CMOS(memory) and exit setup. Confirmation message will be displayed before proceeding

```
SAVE to CMOS and EXIT (Y/N)? Y
```

## Exit Without Saving

Abandon all changes made during the current session and exit setup. confirmation message will be displayed before proceeding.

```
Quit Without Saving (Y/N)? N
```

## Upgrade BIOS

This submenu allows you to upgrade bios.

```
BIOS UPDATE UTILITY (Y/N)? N
```




# P4TDQ Pro BIOS Setup

## 2 Standard CMOS Features

The items in Standard CMOS Setup Menu are divided into 10 categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

■ **Figure 2. Standard CMOS Setup**



# P4TDQ Pro BIOS Setup

---

## Main Menu Selections

This table shows the selections that you can make on the Main Menu.

<b>Item</b>	<b>Options</b>	<b>Description</b>
Date	mm : dd : yy	Set the system date. Note that the 'Day' automatically changes when you set the date.
Time	hh : mm : ss	Set the system internal clock.
IDE Primary Master	Options are in its sub menu.	Press <Enter> to enter the sub menu of detailed options
IDE Primary Slave	Options are in its sub menu.	Press <Enter> to enter the sub menu of detailed options.
IDE Secondary Master	Options are in its sub menu.	Press <Enter> to enter the sub menu of detailed options.
IDE Secondary Slave	Options are in its sub menu.	Press <Enter> to enter the sub menu of detailed options.
Drive A Drive B	360K, 5.25 in 1.2M, 5.25 in 720K, 3.5 in 1.44M, 3.5 in 2.88M, 3.5 in None	Select the type of floppy disk drive installed in your system.
Video	EGA/VGA CGA 40 CGA 80 MONO	Select the default video device.

## ***P4TDQ Pro BIOS Setup***


---

<b>Item</b>	<b>Options</b>	<b>Description</b>
Halt On	All Errors No Errors All, but Keyboard All, but Diskette All, but Disk/ Key	Select the situation in which you want the BIOS to stop the POST process and notify you.
Base Memory	N/A	Displays the amount of conventional memory detected during boot up.
Extended Memory	N/A	Displays the amount of extended memory detected during boot up.
Total Memory	N/A	Displays the total memory available in the system.

# P4TDQ Pro BIOS Setup

## 3 Advanced BIOS Features

■ Figure 3. Advanced BIOS Setup



### Virus Warning

This option allows you to choose the Virus Warning feature that is used to protect the IDE Hard Disk boot sector. If this function is enabled and an attempt is made to write to the boot sector, BIOS will display a warning message on the screen and sound an alarm beep.

<b>Disabled</b> (default)	Virus protection is disabled.
Enabled	Virus protection is activated.

### Quick Power On Self Test

Enabling this option will cause an abridged version of the Power On Self-Test (POST) to execute after you power up the computer.

<b>Enabled</b> (default)	Enable quick POST.
Disabled	Normal POST.

### Boot Up NumLock Status

Selects the NumLock. State after power on.

<b>On</b> (default)	Numpad is number keys.
Off	Numpad is arrow keys.

# P4TDQ Pro BIOS Setup

---

## Gate A20 Option

Select if chipset or keyboard controller should control Gate A20.

- |                       |   |
|-----------------------|---|
| Normal                | A pin in the keyboard controller controls Gate A20. |
| <b>Fast</b> (default) | Lets chipset control Gate A20.                      |

## Typematic Rate Setting

When a key is held down, the keystroke will repeat at a rate determined by the keyboard controller. When enabled, the typematic rate and typematic delay can be configured.

- Disabled** (default)  
Enabled

## Typematic Rate (Chars/Sec)

Sets the rate at which a keystroke is repeated when you hold the key down.

**The Choices:** 6 (default), 8,10,12,15,20,24,30.

## Typematic Delay (Msec)

Sets the delay time after the key is held down before it begins to repeat the keystroke.

**The Choices:** 250 (default), 500,750,1000.

## Security Option

This option will enable only individuals with passwords to bring the system online and/or to use the CMOS Setup Utility.

- |                        |   |
|------------------------|---|
| System                 | A password is required for the system to boot and is also required to access the Setup Utility. |
| <b>Setup</b> (default) | A password is required to access the Setup Utility only.  |

This will only apply if passwords are set from the Setup main menu.

## APIC Mode

By selecting Enabled enables ACPI device mode reporting from the BIOS to the operating system.

**The Choices:** Enabled (default), Disabled.

## MPS Version Control For OS

The BIOS supports version 1.1 and 1.4 of the Intel multiprocessor specification.

Select version supported by the operation system running on this computer.

**The Choices:** 1.4 (default), 1.1.

## OS Select For DRAM > 64MB

A choice other than Non-OS2 is only used for OS2 systems with memory exceeding 64MB.

**The Choices:** Non-OS2 (default), OS2.

# ***P4TDQ Pro BIOS Setup***

---

## **Small Logo(EPA) Show**

This item allows you to enable/ disable display the small EPA logo.

**The Choices:** Disabled (default), Enabled.

## **Summary Screen Show**

This item allows you to enable/ disable display the Summary Screen Show.

**The Choices:** Disabled (default), Enabled.

## **Boot Seq & Floppy Setup**

### **First/ Second/ Third/ Boot Other Device**

These BIOS attempt to load the operating system from the device in the sequence selected in these items.

**The Choices:** Floppy, LS120, HDD-0, SCSI, CDROM, HDD-1, HDD-2, HDD-3, ZIP 100, LAN, HPT370, Disabled.

### **Swap Floppy Drive**

For systems with two floppy drives, this option allows you to swap logical drive assignments.

**The Choices:** Disabled (default), Enabled.

### **Boot Up Floppy Seek**

Enabling this option will test the floppy drives to determine if they have 40 or 80 tracks. Disabling this option reduces the time it takes to boot-up.


**The Choices:** Disabled, **Enabeld** (default).

# P4TDQ Pro BIOS Setup

## 4 Advanced Chipset Features

This submenu allows you to configure the specific features of the chipset installed on your system. This chipset manage bus speeds and access to system memory resources, such as DRAM. It also coordinates communications with the PCI bus. The default settings that came with your system have been optimized and therefore should not be changed unless you are suspicious that the settings have been changed incorrectly.

■ **Figure 4. Advanced Chipset Setup**



### DRAM Timing Selectable

When synchronous DRAM is installed, the number of clock cycles of CAS latency depends on the DRAM timing.

**The Choices:** By SPD (default), Manual.

### CAS Latency Time

When synchronous DRAM is installed, the number of clock cycles of CAS latency depends on the DRAM timing.

**The Choices:** 1.5 (default), 2, 2.5.

### Active to Precharge Delay

This item controls the number of DRAM clocks to activate the precharge delay.

**The Choices:** 7 (default), 6, 5.

# ***P4TDQ Pro BIOS Setup***

---

## **DRAM RAS# to CAS# Delay**

This field let you insert a timing delay between the CAS and RAS strobe signals, used when DRAM is written to, read from, or refreshed. Fast gives faster performance; and slow gives more stable performance. This field applies only when synchronous DRAM is installed in the system.

**The Choices:** 3 (default), 2.

## **DRAM RAS# Precharge**

If an insufficient number of cycle is allowed for RAS to accumulate its charge before DRAM refresh, the refresh may be incomplete, and the DRAM may fail to retain data. Fast gives faster performance; and Slow gives more stable performance. This field applies only when synchronous DRAM is installed in the system.

**The Choices:** 3 (default), 2.

## **Turbo Mode**

This option allows you to enable or disable Turbo Mode.

**The Choices:** Enabled (Default), Disabled.

## **Memory Frequency For**

This item allows you to select the Memory Frequency.

**The Choices:** Auto (default), DDR200, DDR266.

## **System BIOS Cacheable**

Selecting Enabled allows you caching of the system BIOS ROM at F0000h~FFFFh, resulting a better system performance. However, if any program writes to this memory area, a system error may result.

**The Choices:** Enabled (default), Disabled.

## **Video BIOS Cacheable**

Select Enabled allows caching of the video BIOS, resulting a better system performance. However, if any program writes to this memory area, a system error may result.

**The Choices:** Disabled (default), Enabled.

## **Video RAM Cacheable**

Enabling this option allows caching of the video RAM, resulting a better system performance. However, if any program writes to this memory area, a system error may result.

**The Choices:** Disabled (default), Enabled.

## **Memory Hole At 15M-16M**

You can reserve this area of system memory for ISA adapter ROM. When this area is



## ***P4TDQ Pro BIOS Setup***

---

reserved it cannot be cached. The user information of peripherals that need to use this area of system memory usually discussed their memory requirements.

**The Choices:** Disabled (default), Enabled.

### **Delayed Transaction**

The chipset has an embedded 32-bit posted write buffer to support delay transactions cycles. Select Enabled to support compliance with PCI specification.

**The Choices:** Enabled (default), Disabled.

### **AGP Aperture Size (MB)**

Select the size of the Accelerated Graphics Port (AGP) aperture. The aperture is a portion of the PCI memory address range dedicated for graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation.

**The Choices:** 64 (default), 4, 8, 16, 32, 128, 256.

### **On-Chip Frame Buffer Size**


This item allows you to choose the on-chip frame buffer size.

**The Choices:** 8MB (default), 1MB.

# P4TDQ Pro BIOS Setup

## 5 Integrated Peripherals

■ Figure 5. Integrated Peripherals



### Onboard PCI LAN

This item allows you to enable or disable Onboard PCI LAN.

**The Choices:** Enabled (default), Disabled.

### Onboard LAN Boot ROM

This item allows you to enable or disable Onboard LAN Boot ROM.

**The Choices:** Disabled (default), Enabled.

### USB Controller

Select Enabled if your system contains a Universal Serial Bus (USB) controller and you have USB peripherals.

**The Choices:** Enabled (default), Disabled.

# ***P4TDQ Pro BIOS Setup***

---

## **USB EHCI Controller**

This item allows you to enable or disable the USB EHCI Controller integrated in ICH4.

**The Choices:** Enabled (default), Disabled.

## **USB Keyboard Support**

The default value is Disabled.

Enabled

Enable USB Keyboard Support.

Disabled (default)

Disable USB Keyboard Support.

## **AC97 Audio**

This item allows you to decide to enable/disable to support AC97 Audio.

**The Choices:** Auto (default), Disabled.

## **AC97 Modem**

This item allows you to decide to enable/disable to support AC97 Modem.

**The Choices:** Auto (default), Disabled.

## **Init Display First**

This item allows you to decide to active whether PCI Slot or on-chip VGA first.

**The Choices:** Onboard/AGP (default), PCI Slot.

## **IDE HDD Block Mode**

Block mode is also called block transfer, multiple commands, or multiple sector read/write. If your IDE hard drive supports block mode (most new drives do), select Enabled for automatic detection of the optimal number of block mode (most new drives do), select Enabled for automatic detection of the optimal number of block read/write per sector where the drive can support.

**The Choices:** Enabled (default), Disabled.

## **Delay For HDD Detect**

Some old hard disk drive need much time to wait it ready, if your hard disk drive can not be detected try to set this item to enable.

**The Choices:** Disabled (Default), Enabled.

## **Onboard I/O Chip Setup**

Press Enter to configure Super IO device.

### **Onboard FDC Controller**

Select Enabled if your system has a floppy disk controller (FDC) installed on the system board and you wish to use it. If install and FDC or the system has no floppy drive, select Disabled in this field.

# P4TDQ Pro BIOS Setup

---

**The Choices:** Enabled (default), Disabled.

## Onboard Serial Port 1

Select an address and corresponding interrupt for the first and second serial ports.

**The Choices:** 3F8/IRQ4 (default), Disabled, Auto, 2F8/IRQ3, 3E8/IRQ4, 2E8/IRQ3.

## Onboard Serial Port 2

Select an address and corresponding interrupt for the first and second serial ports

**The Choices:** 2F8/IRQ3, Disabled (default), Auto, 3F8/IRQ4, 3E8/IRQ4, 2E8/IRQ3.

## UART Mode Select

This item allows you to determine which Infrared (IR) function of onboard I/O chip.

**The Choices:** Normal, ASKIR, IrDA (default), SCR.

## UR2 Duplex Mode

Select the value required by the IR device connected to the IR port. Full-duplex mode permits simultaneous two-direction transmission. Half-duplex mode permits transmission in one direction only at a time.

**The Choices:** Half (default), Full.

## Onboard Parallel Port

This item allows you to determine access onboard parallel port controller with which I/O Address.

**The Choices:** 378/IRQ7 (default), 278/IRQ5, 3BC/IRQ7, Disabled.

## Parallel Port Mode

The default value is SPP.

SPP (default)                      Using Parallel Port as Standard Printer Port.

EPP                                      Using Parallel Port as Enhanced Parallel Port.

ECP                                      Using Parallel Port as Extended Capabilities Port.

ECP+EPP                      Using Parallel Port as ECP & EPP mode.

## ECP Mode Use DMA

Select a DMA Channel for the port.

**The Choices:** 3 (default), 1.

## Game Port Address

Game Port I/O Address.

**The Choices:** 201 (default), 209, Disabled.

## Midi Port Address

Midi Port Base I/O Address.

# ***P4TDQ Pro BIOS Setup***

---

**The Choices:** 330 (default), 300, Disabled.

## **Midi Port IRQ**

This determines the IRQ in which the Midi Port can use.

**The Choices:** 10 (default), 5.

## **IDE Device Control**

If you highlight the literal "Press Enter" next to the "IDE Device Control" label and then press the enter key, it will take you a submenu with the following options:

### **On-Chip Primary / Secondary PCI IDE**

This item allows you to enable/ disable On-Chip Primary PCI IDE

**The Choices:** Enabled (default), Disabled.

### **IDE Primary / Secondary Master / Slave PIO**

The IDE PIO (Programmed Input / Output) fields let you set a PIO mode (0-4) for each of the IDE devices that the onboard IDE interface supports. Mode 0 through 4 provide successively increased performance. In Auto mode, the system automatically determine the best mode for each device.

**The Choices:** Auto (default), Mode0, Mode1, Mode2, Mode3, Mode4.

### **Primary / Secondary Master / Slave UDMA**

Ultra DMA/ 100 functionality can be implemented if it is supported by the IDE hard drives in your system. As well, your operating environment requires a DMA driver. If your hard drive and your system software both support Ultra DMA/ 100, select Auto to enable BIOS support.


**The Choices:** Auto (default), Disabled.

# P4TDQ Pro BIOS Setup

## 6 Power Management Setup

The Power Management Setup Menu allows you to configure your system to utilize energy conservation and power up/power down features.

■ **Figure 6. Power Management Setup**



### ACPI function

This item displays the status of the Advanced Configuration and Power Management (ACPI).

**The Choices:** Enabled (default), Disabled.

### ACPI Suspend Type

The item allows you to select the suspend type under the ACPI operating system.

**The Choices:** S1 (POS) (default) Power on Suspend  
S3 (STR) Suspend to RAM  
S1 & S3 POS+STR

### Run VGABIOS if S3 Resume

Choosing Enabled will make BIOS run VGA BIOS to initialize the VGA card when system

# **P4TDQ Pro BIOS Setup**

---

wakes up from S3 state . The system time is shortened if you disable the function , but system will need AGP driver to initialize the card . So , if the AGP driver of the VGA card does not support the initialization feature , the display may work abnormally or not function after S3 .

**The Choices:**Auto (default), Yes, No.

## **Power Management**

This category allows you to select the type (or degree) of power saving and is directly related to the following modes:

- 1.HDD Power Down.
- 2.Suspend Mode.

There are four options of Power Management, three of which have fixed mode settings

### **Min. Power Saving**

Minimum power management.  
Suspend Mode = 1 hr.  
HDD Power Down = 15 min

### **Max. Power Saving**

Maximum power management only available for sl CPU's.  
Suspend Mode = 1 min.  
HDD Power Down = 1 min.

### **User Defined (default)**

Allows you to set each mode individually.  
When not disabled, each of the ranges are from 1 min. to 1 hr. except for HDD Power Down which ranges from 1 min. to 15 min. and disable.

## **Video Off Method**

This option determines the manner in which the monitor is goes blank.

### **V/H SYNC+Blank**

This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.  
**Blank Screen**

This option only writes blanks to the video buffer.

### **DPMS (default)**

Initial display power management signaling

# ***P4TDQ Pro BIOS Setup***

---

## **Video Off In Suspend**

This determines the manner in which the monitor is blanked.

**The Choices:** Yes (default), No.

## **Suspend Type**

Select the Suspend Type.

**The Choices:** Stop Grant, **PwrOn Suspend** (default).

## **Modem Use IRQ**

This determines the IRQ, which can be applied in MODEM use.

**The Choices:** 3 (default), 4 / 5 / 7 / 9 / 10 / 11 / NA.

## **Suspend Mode**

When enabled and after the set time of system inactivity, all devices except the CPU will be shut off.

**The Choices:** **Disabled** (default), 1Min, 2Min, 4Min, 8Min, 12Min, 20Min, 30Min, 40Min, 1Hour.

## **HDD Power Down**

When enabled and after the set time of system inactivity, the hard disk drive will be powered down while all other devices remain active.

**The Choices:** **Disabled** (default), 1Min, 2Min, 3Min, 4Min, 5Min, 6Min, 7Min, 8Min, 9Min, 10Min, 11Min, 12Min, 13Min, 14Min, 15Min.

## **Soft-Off by PWR-BTTN**

Pressing the power button for more than 4 seconds forces the system to enter the Soft-Off state when the system has "hung."

**The Choices:** **Delay 4 Sec** (default), Instant-Off.

## **CPU THRM-Throttling**

Select the CPU THRM-Throttling rate.

**The Choices:** 87.5%, 75.5%, 62.5%, **50.0%** (default), 37.5%, 25%, 12.5%.

## **Wake-Up/Power On Control**

If you highlight the literal "Press Enter" next to the "Wake-Up/ Power On Control" lable and then press the enter key, it will take you a submenu with the following options:

### **Wake-Up by PCI card**

When you select Enable, a PME signal from PCI card returns the system to Full On state.

**The Choices:** Enabled, **Disabled** (default).



# P4TDQ Pro BIOS Setup

---

## Power On by Ring

An input signal on the serial Ring Indicator (RI) line (in other words, an incoming call on the modem) awakens the system from a soft off state.

**The Choices:** Enabled, **Disabled** (default).

## Wake Up On LAN

To use this function, you need a LAN add-on card which support power on function. It should also support the wake-up on LAN jumper.

**The Choices:** Enabled, **Disabled** (default).

## USB KB Wake-Up From S3

This item allows you to enable/ disable USB KB wake up from S3.

**The Choices:** **Disabled** (default), Enabled.

## Resume by Alarm

This function is for setting date and time for your computer to boot up. During Disabled, you cannot use this function. During Enabled, Choose the Date and Time.

Alarm:     **Date (of Month) Alarm**     You can choose which month the system will boot up.

**Time (hh:mm:ss) Alarm**     You can choose what hour, minute and second the system will boot up.

*Note:*     If you have change the setting, you must let the system boot up until it goes to the operating system, before this function will work.

## KBD Power On Function

This item allows you to select the various functions of KB to power on the systems.

**The Choices:** **Disabled** (Default), Password, Hot Key, Mouse Move, Mouse Click, Any Key, Keyboard 98.

## KB Power On Password

This item allows you to enter a password with at least 5 characters.

## HOT Key Power On

This item allows you to set the hot key to power on system.

**The Choices:** **Ctrl-F1** (Default), Ctrl-F2, Ctrl-F3, Ctrl-F4, Ctrl-F5, Ctrl-F6, Ctrl-F7, Ctrl-F8, Ctrl-F9, Ctrl-F10, Ctrl-F11, Ctrl-F12.

## PWRON After PWR-Fail

This field determines the action the system will automatically take when power is restored to a system that had lost power previously without any subsequent manual intervention. There are 3 sources that provide current to the CMOS area that retains these Power-On instructions; the motherboard battery (3V), the Power Supply (5VSB), and the Power Supply (3.3V). While AC is not supplying power, the motherboard uses the motherboard battery (3V). If AC power is supplied and the Power Supply is not turned on, 5VSB from the Power Supply is used. When the Power Supply is eventually turned on 3.3V from the Power Supply will be

## ***P4TDQ Pro BIOS Setup***

---

used.

There are 3 options: "Former-Sts", "On", "Off".

"Former-Sts"	Means to maintain the last status of the CMOS when AC power is lost.
"On"	Means always set CMOS to the "On" status when AC power is lost
"Off" (default)	Means always set CMOS to the "Off" status when AC power is lost.

For example: If set to "Former-Sts" and AC power is lost when system is live, then after AC power is restored, the system will automatically power on. If AC power is lost when system is not live, system will remain powered off.

### **Reload Global Timer Event**

Reload Global Timer Events are I/O events whose occurrence can prevent the system from entering a power saving mode or can awaken the system from such a mode. In effect, the system remains alert for anything, which occurs to a device, which is configured as *Enabled*, even when the system is in a power down mode.

**Primary IDE 0/1**

**Secondary IDE 0/1**

**FDD, COM, LPT Port**


**PCI PIRQ [A-D]#**

# P4TDQ Pro BIOS Setup

## 7 PnP/PCI Configurations

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself uses when communicating with its own special components. This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.

### ■ Figure 7. PnP/PCI Configurations



### Reset Configuration Data

The system BIOS supports the PnP feature which requires the system to record which resources are assigned and protects resources from conflict. Every peripheral device has a node, which is called ESCD. This node records which resources are assigned to it. The system needs to record and update ESCD to the memory locations. These locations (4K) are reserved in the system BIOS. If the Disabled (default) option is chosen, the system's ESCD will update only when the new configuration varies from the last one. If the Enabled option is chosen, the system is forced to update ESCDs and then is automatically set to the "Disabled" mode.

The above settings will be shown on the screen only if "Manual" is chosen for the resources

# P4TDQ Pro BIOS Setup

---

controlled by function.

Legacy is the term, which signifies that a resource is assigned to the ISA Bus and provides non-PnP ISA add-on cards. PCI / ISA PnP signifies that a resource is assigned to the PCI Bus or provides for ISA PnP add-on cards and peripherals.

**The Choices:** Disabled (default), Enabled.

## Resources Controlled By

By Choosing “**Auto(ESCD)**” (default), the system BIOS will detect the system resources and automatically assign the relative IRQ and DMA channel for each peripheral. By Choosing “Manual”, the user will need to assign IRQ & DMA for add-on cards. Be sure that there are no IRQ/DMA and I/O port conflicts.

## IRQ Resources

This submenu will allow you to assign each system interrupt a type, depending on the type of device using the interrupt. When you press the “Press Enter” tag, you will be directed to a submenu that will allow you to configure the system interrupts. This is only configurable when “Resources Controlled By” is set to “Manual”.

IRQ-3	assigned to	PCI Device
IRQ-4	assigned to	PCI Device
IRQ-5	assigned to	PCI Device
IRQ-7	assigned to	PCI Device
IRQ-9	assigned to	PCI Device
IRQ-10	assigned to	PCI Device
IRQ-11	assigned to	PCI Device
IRQ-12	assigned to	PCI Device
IRQ-14	assigned to	PCI Device
IRQ-15	assigned to	PCI Device

## PCI / VGA Palette Snoop

Choose Disabled or Enabled. Some graphic controllers which are not VGA compatible take the output from a VGA controller and map it to their display as a way to provide boot information and VGA compatibility.

However, the color information coming from the VGA controller is drawn from the palette table inside the VGA controller to generate the proper colors, and the graphic controller needs to know what is in the palette of the VGA controller. To do this, the non-VGA graphic controller watches for the Write access to the VGA palette and registers the snoop data. In PCI based systems, where the VGA controller is on the PCI bus and a non-VGA graphic controller is on an ISA bus, the Write Access to the palette will not show up on the ISA bus if the PCI VGA controller responds to the Write.


In this case, the PCI VGA controller should not respond to the Write, it should only snoop the data and permit the access to be forwarded to the ISA bus. The non-VGA ISA graphic controller can then snoop the data on the ISA bus. Unless you have the above situation, you should disable this option.

<b>Disabled</b> (default)	Disables the function.
Enabled	Enables the function.

# P4TDQ Pro BIOS Setup

## 8 PC Health Status

■ Figure 8. PC Health Status



### Shutdown Temperature

This item allows you to set up the CPU shutdown Temperature. This item only effective under Windows 98 ACPI mode.

**The Choices:** Disabled (default), 60°C/140°F, 65°C/149°F, 70°C/158°F, 75°C/167°F.

### CPU Vcore/AGP Voltage/+3.3V/+5V/+12V/-12V/-5V/ Voltage Battery

Detect the system's voltage status automatically.

### Current CPU Temp

Show you the current CPU1 temperature.

### Current CPU FAN Speed

This field displays the current CPUFAN speed.

### Current SYS FAN Speed

This field displays the current speed SYSTEM fan.

# ***P4TDQ Pro BIOS Setup***

---

## **Show H/W Monitor in POST**


If your computer contains a monitoring system, it will show PC health status during POST stage. The item offers several delay times to select the one you want.

**The Choices:** **Enabled** (default), Disabled .

# P4TDQ Pro BIOS Setup

## 9 Frequency Control

■ Figure 9. Frequency Control



### CPU Clock Ratio

This item allows you to select the CPU Ratio.

### CPU Voltage

This item allows you to select CPU Voltage Regulator.

**The Choices:** Default (default), +1.7%, +3.45%, +5.1%.

### DDR Voltage

This item allows you to select the SDRAM Voltage.

**The Choices:** 2.5V (default), 2.6V, 2.7V, 2.8V.

### Auto Detect DIMM/PCI Clk

This item allows you to enable / disable auto Detect DIMM/PCI Clock.

**The Choices:** Enabled (default), Disabled.

### CPU Clock

This item allows you to select CPU Clock, and CPU over clocking.

## **P4TDQ Pro BIOS Setup**

---



If unfortunately, the system's frequency that you are selected is not functioning, there are two methods of booting-up the system.

Method 1: Clear the COMS data by setting the JCOMS1 ((2-3 closed)) as "ON" status. All the CMOS data will be loaded as defaults setting.

Method 2: Press the <Insert> key and Power button simultaneously, after that keep-on pressing the <Insert> key until the power-on screen showed. This action will boot-up the system according to FSB of the processor.

※ **It's strongly recommended to set CPU Vcore and clock in default setting. If the CPU Vcore and clock are not in default setting, it may cause CPU or M/B damage.**